


–weishaupt–

manual

Installation and operating instruction



Conformity certification

4820000002

Manufacturer:

Max Weishaupt GmbH

Address:

**Max-Weishaupt-Straße
D-88475 Schwendi**

Product: Gas condensing boiler

**WTC-GB 90-A, WTC-GB 120-A,
WTC-GB 170-A, WTC-GB 210-A,
WTC-GB 250-A, WTC-GB 300-A**

The product described above conforms with

the regulations of directives:

GAD	2009 / 142 / EC
LVD	2006 / 95 / EC
EMC	2004 / 108 / EC
BED	92 / 42 / EEC

This product is labelled as follows:

CE

CE-0085

Schwendi, 14.07.2010

ppa.



Dr. Lück

ppa.



Denking

1	User instructions	6
1.1	User guide	6
1.1.1	Symbols	6
1.1.2	Target group	6
1.2	Guarantee and Liability	7
2	Safety	8
2.1	Permissible application	8
2.2	When gas can be smelled	8
2.3	What to do if flue gas can be smelled	8
2.4	Safety measures	8
2.4.1	Normal operation	8
2.4.2	Electrical connection	9
2.4.3	Gas supply	9
2.5	Disposal	9
3	Product description	10
3.1	Type key	10
3.2	Function	10
3.2.1	Components	10
3.2.2	Electrical parts	11
3.2.3	Safety devices	12
3.2.4	Program sequence	13
3.3	Technical data WTC 120 / WTC 170	14
3.3.1	Approval data	14
3.3.2	Electrical data	14
3.3.3	Ambient conditions	14
3.3.4	Permissible fuels	14
3.3.5	Emissions	14
3.3.6	Rating	15
3.3.7	Heat exchanger	15
3.3.8	Flue gas system data	16
3.3.9	EnEV Product Characteristics	16
3.3.10	Dimensions	17
3.3.11	Weight	17
3.4	Technical data WTC 210 / WTC 250 / WTC 300	18
3.4.1	Approval data	18
3.4.2	Electrical data	18
3.4.3	Ambient conditions	18
3.4.4	Permissible fuels	18
3.4.5	Emissions	18
3.4.6	Rating	19
3.4.7	Heat exchanger	19
3.4.8	Flue gas system data	20
3.4.9	EnEV Product Characteristics	20
3.4.10	Dimensions	21
3.4.11	Weight	21
4	Installation	22

5	Installation	24
5.1	Requirements for the heating water	24
5.1.1	Permissible water hardness	24
5.1.2	Fill water quantity	25
5.1.3	Treatment of fill and top-up water	26
5.2	Hydraulic connection	27
5.3	Condensate connection	28
5.4	Gas supply	29
5.5	Routing of air/ flue gas circulation	30
5.6	Electrical installation	31
5.6.1	Wiring diagram	32
5.6.2	Connection additional pump via output VA1	33
6	Operation	34
6.1	Operating interface	34
6.1.1	Operating panel	34
6.1.2	Display	35
6.2	End User Level	36
6.2.1	Display End User Level	36
6.2.2	Settings End User Level	37
6.3	Heating Engineer Level	38
6.3.1	Info level	39
6.3.2	Parameter level	41
6.4	Manual start up	44
6.5	Start manual configuration	45
6.6	Control options	46
6.7	Control options	46
6.8	Boiler circuit pump	48
6.8.1	General information	48
6.8.2	Speed controlled pump	48
6.9	Frost protection	49
6.10	Inputs and outputs	50
6.11	Special system parameters	52
6.11.1	System parameters WTC 120 / WTC 170	52
6.11.2	System parameters WTC 210 / WTC 250 / WTC 300	53
6.12	Chimney sweep function	54
7	Commissioning	55
7.1	Prerequisite	55
7.1.1	Check soundness of gas valve train	56
7.1.2	Check gas connection pressure	57
7.2	Adjusting the boiler	58
7.3	Calculate combustion heat rating	61
8	Shutdown	62
9	Servicing	63
9.1	Safety components	65
9.2	Servicing display	65
9.3	Check differential pressure at air pressure switch	66

9.4	Replacing electrodes	67
9.5	Removing and refitting burner tube	68
9.6	Cleaning the heat exchanger	71
9.7	Check flue gas pressure switch	72
10	Troubleshooting	73
10.1	Procedures for fault conditions	73
10.2	Fault history	74
10.3	Rectifying faults	75
10.3.1	Warning codes	75
10.3.2	Error codes	77
10.3.3	Operating problems	79
11	Spares	80
12	Technical documentation	100
12.1	Internal boiler wiring	100
12.2	Sensor variables	101
12.3	Pneumatic control lines	102
12.3.1	Air pressure switch connection diagram	102
12.3.2	Flue gas pressure switch connection diagram	102
12.4	Conversion table O ₂ /CO ₂	103
13	Notes	104
14	Key word index	105

1 User instructions









1 User instructions

Translation of original
operating instructions

These installation and operating instructions form part of the unit and must be kept on site.

1.1 User guide

1.1.1 Symbols

 DANGER	Immediate danger with high risk. Non observance can lead to serious injury or death.
 WARNING	Danger with medium risk. Non observance can lead to environmental damage, serious injury or death.
 CAUTION	Danger with low risk. Non observance can cause damage to the equipment and injury to personnel.
	Important information.
	Requires direct action.
	Result after an action.
	Itemisation.
	Range.

1.1.2 Target group

These installation and operating instructions are intended for the operator and qualified personnel. They should be observed by all personnel working on the unit.

Work on the unit must only be carried out by personnel who have the relevant training and instruction.

Persons with limited physical, sensory or mental capabilities may only work on the unit if they are supervised or have been trained by an authorised person.

Children must not play near or on the unit.

1 User instructions

1.2 Guarantee and Liability

Guarantee and liability claims for personal and equipment damage are excluded, if they can be attributed to one or more of the following causes:

- Non approved application,
- non-observance of the installation and operating instruction,
- operation with faulty safety equipment,
- continual operation despite a fault,
- improper installation, commissioning, operation and service,
- unauthorised modifications made to the unit,
- the installation of additional components, which have not been tested with the unit,
- the installation of combustion chamber inserts, which impede full flame formation,
- repairs, which have been carried out incorrectly,
- the use of non original Weishaupt parts,
- unsuitable fuels,
- defects in the inlet lines,
- on non diffusion tight heating circuits without system separation,
- acts of God.

2 Safety

2 Safety

2.1 Permissible application

The boiler is suitable for:

- Warm water heating circuits in closed systems according to DIN EN 12828
- A flow rate of maximum:
 - WTC 120 = 10.3 m³/h,
 - WTC 170 = 14.2 m³/h,
 - WTC 210 = 18.0 m³/h,
 - WTC 250 = 21.5 m³/h,
 - WTC 300 = 25.0 m³/h.

The combustion air must be free from aggressive compounds (e.g. Halogens). If the combustion air in the boiler room is contaminated, increased cleaning and servicing will be required. In this case the unit should be operated room air independent.

The unit should only be used in enclosed rooms. The installation room must comply with local regulations.

Improper use could:

- endanger the health and safety of the user or third parties,
- cause damage to the appliance or other material assets.

2.2 When gas can be smelled

Avoid open flames and spark generation, for example:

- do not operate light switches,
- do not operate electronic equipment,
- do not use mobile telephones.
- ▶ Open doors and windows.
- ▶ Close gas isolating valve.
- ▶ Warn the inhabitants (do not ring door bells).
- ▶ Leave the building.
- ▶ Inform the heating company or gas supplier from outside of the building.

2.3 What to do if flue gas can be smelled

- ▶ Switch off unit and turn off installation.
- ▶ Open doors and windows.
- ▶ Inform heating company.

2.4 Safety measures

- Rectify safety-relevant defects immediately,
- Replace safety-relevant components according to their specified service life (see Ch. 9.1).

2.4.1 Normal operation

- All labels on the unit must be kept in a legible condition,
- only operate the unit with its cover in the closed position,
- stipulated settings, service and inspection work should be carried out at regular intervals.

2 Safety

2.4.2 Electrical connection

For all work carried out on live parts:

- Observe the accident prevention instructions BGV A3 and adhere to local directives,
- tools in accordance with EN 60900 should be used.

2.4.3 Gas supply

- Only the gas supplier or an approved agent may carry out installation, alteration and maintenance work on gas appliances in buildings and properties.
- Pipe work must be subject to a pre and main test and a combined load and valve proving test relative to the pressure range intended (e.g. DVGW-TRGI, work sheet G 600).
- Inform the gas supplier about the type and size of plant prior to installation.
- Local regulations and guidelines must be observed during installation (e. g. DVGW-TRGI, work sheet G 600)..
- The gas supply pipe work should be suitable for the type and quality of gas and should be designed in such a way that it is not possible for liquids to form (e. g. condensate).
- Use only tested and approved sealing materials, whilst observing all process information.
- Re-commission the appliance when changing to a different type of gas.
- Carry out soundness test after each service and fault rectification.

2.5 Disposal

Dispose of all materials used in a safe and environmentally friendly way. Observe local regulations.

3 Product description

3 Product description


3.1 Type key

Example: WTC-GB 170-A

WTC	Weishaupt Thermo Condens
-G	Fuel: Gas
B	Type of construction: floor standing
170	Ratings size: 170 kW
-A	Construction

3.2 Function


3.2.1 Components



- ① Heat exchanger section
- ② Flow manifold with 2" pipe connection
- ③ Safety valve connection
- ④ 1" Gas pipe
- ⑤ Air inlet pipe DN 110
- ⑥ Siphon
- ⑦ Condensate collector with flue gas connection
- ⑧ Inlet and outlet tap
- ⑨ Return manifold with 2" pipe connection
- ⑩ Sound absorber (except WTC 250 and WTC 300)
- ⑪ Venturi

3 Product description

3.2.2 Electrical parts



- ① Safety temperature limiter (eSTL)
- ② Ignition electrode
- ③ Boiler control panel (WCM-CUI)
- ④ Gas combi valve
- ⑤ Connection box (W-EAB)
- ⑥ Boiler electronics (WCM-CPU)
- ⑦ Ionisation electrode
- ⑧ Ignition unit
- ⑨ Fan
- ⑩ Supply sensor
- ⑪ Flue gas sensor
- ⑫ Return sensor
- ⑬ Water level interlock
- ⑭ Air pressure switch
- ⑮ Flue gas pressure switch

3 Product description

3.2.3 Safety devices

Safety temperature limiter (eSTL)

The fuel supply is shut off and the fan and the pump run-on are activated if the temperature on the eSTL exceeds a value of 95 °C (W12). The boiler restarts automatically, if the temperature drops below the flow setpoint value for 1 minute.

The fuel supply is shut off and the fan and the pump run-on are activated if the temperature on the eSTL exceeds 105 °C. The installation goes to lockout (F11).

Temperature differential supply/return

The boiler is switched off (W15) if the difference between supply and return temperature exceeds the value of parameter A21. If the warning appears 30 times consecutively, the boiler goes to lockout (F15). If this value is approached, the pump rating is increased to 100 % and the burner rating is gradually reduced.

Temperature differential eSTL/supply sensor

If the difference between eSTL and supply temperature exceed the value of parameter A22, the boiler is switched off (W18). The installation goes to lockout after 30 warnings with (F18).

Monitoring supply temperature increase (gradient)

If the temperature at the eSTL increases too rapidly (parameter A23), the boiler is switched off (W14). This function is only activated at a temperature of > 45 °C.

Flue gas sensor

The fuel supply will be switched off if the flue gas temperature exceeds the value defined in parameter 33 (factory setting 120 °C). The fan and pump run-on is activated (W16).

Air pressure switch

The air pressure switch monitors the fan pressure. Before the pre-purge phase is started, the idle position of the switch contact is checked. During the pre-purge phase the fan rotation is checked. The system goes to lockout after 4 failed start attempts (F32, F45).

Flue gas pressure switch

During operation, the pressure in the condensate collector is monitored. This stops the siphon from being squeezed empty if the backpressure is too high. If the pressure switch is activated (>5.5 mbar) the system goes to lockout (F46). If the pressure switch is activated during the idle time of the fan the system also goes to lockout (F38).

Water level interlock

If the system pressure drops below 1 bar, the boiler switches off (F36). If the pressure increases to 1.2 bar again, the boiler automatically restarts.

Gas pressure switch

The gas connection pressure is monitored both prior to and during operation. If the gas pressure set is not maintained, the boiler switches off (W47).

3 Product description

3.2.4 Program sequence

Pre-purge

At heat demand ① the fan starts and drives to pre-purge speed ②.

Ignition

The fan drives down to ignition speed ③, ignition ④ switches on, the gas valves ⑤ open. The ignition spark ignites the fuel. A flame appears.

Safety time

Following the safety time (3.5 seconds) ⑥ ignition is switched off.

Stabilisation of the flame

If a flame signal ⑦ is transmitted, the flame stabilisation time ⑧ will follow.

Delayed heating operation


In the heating operation mode the delayed heating operation ⑨ is carried out first. The heating capacity is restricted for the duration of the delayed time (the delayed heating operation is omitted during DHW operation)

Modulating operation

The internal unit temperature regulator sets the speed setpoint for the fan ⑩ within the programmed load limits.

Post-purge

Following every normal shut down, after faults and after the return of the power supply, the fan is operated at the post-purge speed ⑪.



3 Product description

3.3 Technical data WTC 120 / WTC 170

3.3.1 Approval data

Gas Appliance Category (DE, AT, CH)	I ₂ ELL, I ₂ H
Type of installation	B ₂₃ , B _{23P} ⁽¹⁾ , B ₃₃ , C ₁₃ , C ₃₃ , C ₄₃ , C ₅₃ , C ₆₃ , C ₈₃ , C ₉₃
CE-PIN	CE-0063 BS 3948
SVGW	07-050-4

⁽¹⁾ only in conjunction with a flue gas system in pressure class P1 or H1 to EN 14471.

Basic standards	EN 13 384-1: 2006 and EN 13 384-2: 2003 EN 483: 1999 EN 656: 1999 EN 15417: 2006 EN 15420: 2010 EN 60335-1 and EN 50165 DVGW G 635
-----------------	--

3.3.2 Electrical data

	WTC 120	WTC 170
Supply voltage / frequency	230 V/50 Hz	230 V/50 Hz
Power consumption operation	170 W	260 W
Power consumption standby	7 W	7 W
Internal unit fuse (WCM-CPU)	6.3 AT	6.3 AT
External pre-fuse	max 16 A	max 16 A
Type of protection	IP 20	IP 20

3.3.3 Ambient conditions

Temperature in operation	+3 ... +30 °C
Temperature during transport / storage	-10 ... +60 °C
relative humidity	max 80 %, no dew point

3.3.4 Permissible fuels

Natural Gas

3.3.5 Emissions

The boiler complies with EN 297 Emission Class 5.

Standard emission factor according to DIN 4702 T8 (40/30 °C)

	WTC 120	WTC 170
Nitrogen Oxide NO _x	47 mg/kWh	39 mg/kWh
Carbon Monoxide CO	17 mg/kWh	19 mg/kWh

O₂ content at min and max rating

Rating	min	max
O ₂ content	4.6 %	4.3 %

3 Product description

3.3.6 Rating

	WTC 120	WTC 170
Combustion heat rating Q_c	23.0 ... 115.9 kW	27.0 ... 161.0 kW
Boiler capacity at 80/60 °C	22.4 ... 114.0 kW	26.3 ... 158.4 kW
Boiler capacity at 50/30 °C	25.0 ... 121.9 kW	29.4 ... 170.0 kW
Fan speed	1380 ... 5520 rpm	1260 ... 5700 rpm
Condensate quantity at 50/30 °C	3.1 ... 7.9 L/h	3.7 ... 12.3 L/h
Standard efficiency at 40/30 °C	109.4 % H_i (98.6 % H_s)	109.3 % H_i (98.5 % H_s)


3.3.7 Heat exchanger

	WTC 120	WTC 170
Water content	13.5 litre	16 litre
Boiler temperature	max 85 °C	max 85 °C
Operating pressure	max 6 bar	max 6 bar
Throughput limit	max 10.3 m³/h	max 14.2 m³/h

Pressure loss

Observe the pressure loss of the boiler and the maximum flow rate limit when determining the hydraulic layout of the heating system.

► Determine pressure loss using the diagram.



① Flow rate in m³/h

② Pressure loss in mbar

3 Product description

3.3.8 Flue gas system data


	WTC 120	WTC 170
Residual supply pressure at flue gas outlet	163 Pa	166 Pa
Flue gas mass flow rate	10.3 ... 51.1 g/s	12.1 ... 71.0 g/s
Flue gas temperature at 80/60 °C	56 ... 65 °C	57 ... 68 °C
Flue gas temperature at 50/30 °C	30 ... 46 °C	30 ... 47 °C
Flue gas connection	DN125	DN125
Air intake pipe	DN110	DN110

3.3.9 EnEV Product Characteristics

	WTC 120	WTC 170
Boiler efficiency factor at 100 % rating and at medium boiler temperature 70 °C	98.4 % H _i (88.6 % H _s)	98.4 % H _i (88.6 % H _s)
Boiler efficiency factor at 30 % rating and at return temperature 30 °C	108.8 % H _i (98.0 % H _s)	108.8 % H _i (98.0 % H _s)
Standby loss at 50 K above room temperature	0.36 % 391 W	0.28 % 425 W

3 Product description

3.3.10 Dimensions



- ① Safety valve connection 1 1/4"
- ② Gas pipe 1"
- ③ Air inlet pipe DN 110
- ④ Condensate connection
- ⑤ Flue gas connection DN 160
- ⑥ Return 2"
- ⑦ Supply 2"

3.3.11 Weight

	WTC 120	WTC 170
Empty weight	approx. 152 kg	approx. 172 kg

3 Product description

3.4 Technical data WTC 210 / WTC 250 / WTC 300

3.4.1 Approval data

Gas Appliance Category (DE, AT, CH)	I ₂ ELL, I ₂ H
Type of installation	B ₂₃ , B _{23P} ⁽¹⁾ , B ₃₃ , C ₁₃ , C ₃₃ , C ₄₃ , C ₅₃ , C ₆₃ , C ₈₃ , C ₉₃
CE-PIN	CE-0063 BS 3948
SVGW	07-050-4

⁽¹⁾ only in conjunction with a flue gas system in pressure class P1 or H1 to EN 14471.

Basic standards	EN 13 384-1: 2006 and EN 13 384-2: 2003 EN 483: 1999 EN 656: 1999 EN 15417: 2006 EN 15420: 2010 EN 60335-1 and EN 50165 DVGW G 635
-----------------	--

3.4.2 Electrical data

	WTC 210	WTC 250	WTC 300
Supply voltage / frequency	230 V/50 Hz	230 V/50 Hz	230 V/50 Hz
Power consumption operation	265 W	295 W	389 W
Power consumption standby	7 W	7 W	7 W
Internal unit fuse (WCM-CPU)	6.3 AT	6.3 AT	6.3 AT
External pre-fuse	max 16 A	max 16 A	max 16 A
Type of protection	IP 20	IP 20	IP 20

3.4.3 Ambient conditions

Temperature in operation	+3 ... +30 °C
Temperature during transport / storage	-10 ... +60 °C
relative humidity	max 80 %, no dew point

3.4.4 Permissible fuels

Natural Gas

3.4.5 Emissions

The boiler complies with EN 297 Emission Class 5.

Standard emission factor according to DIN 4702 T8 (40/30 °C)

	WTC 210	WTC 250	WTC 300
Nitrogen Oxide NO _x	43 mg/kWh	47 mg/kWh	54 mg/kWh
Carbon Monoxide CO	14 mg/kWh	17 mg/kWh	14 mg/kWh

O₂ content at min and max rating

Rating	min	max
O ₂ content	4.6 %	4.3 %

3 Product description

3.4.6 Rating

	WTC 210	WTC 250	WTC 300
Combustion heat rating Q_c	44.0 ... 200.0 kW	48.0 ... 239.0 kW	53.0 ... 276.0 kW
Boiler capacity at 80/60 °C	42.9 ... 196.8 kW	46.8 ... 235.2 kW	51.6 ... 271.6 kW
Boiler capacity at 50/30 °C	47.9 ... 210.0 kW	52.3 ... 251.0 kW	57.7 ... 290.0 kW
Fan speed	1440 ... 5580 rpm	1260 ... 5520 rpm	1320 ... 6120 rpm
Condensate quantity at 50/30 °C	4.8 ... 14.1 L/h	6.2 ... 17.4 L/h	5.6 ... 20.0 L/h
Standard efficiency at 40/30 °C	109.7 % H_i (98.8 % H_s)	110.3 % H_i (99.4 % H_s)	110.2 % H_i (99.3 % H_s)


3.4.7 Heat exchanger

	WTC 210	WTC 250	WTC 300
Water content	20 litre	22.5 litre	25 litre
Boiler temperature	max 85 °C	max 85 °C	max 85 °C
Operating pressure	max 6 bar	max 6 bar	max 6 bar
Throughput limit	max 18.0 m³/h	max 21.5 m³/h	max 25.0 m³/h

Pressure loss

Observe the pressure loss of the boiler and the maximum flow rate limit when determining the hydraulic layout of the heating system.

► Determine pressure loss using the diagram.



① Flow rate in m³/h

② Pressure loss in mbar

3 Product description

3.4.8 Flue gas system data


	WTC 210	WTC 250	WTC 300
Residual supply pressure at flue gas outlet	145 Pa	182 Pa	189 Pa
Flue gas mass flow rate	19.5 ... 88.1 g/s	21.6 ... 105.3 g/s	23.8 ... 121.6 g/s
Flue gas temperature at 80/60 °C	58 ... 70 °C	57 ... 70 °C	58 ... 68 °C
Flue gas temperature at 50/30 °C	30 ... 49 °C	30 ... 48 °C	30 ... 46 °C
Flue gas connection	DN160	DN160	DN160
Air intake pipe	DN110	DN110	DN110

3.4.9 EnEV Product Characteristics

	WTC 210	WTC 250	WTC 300
Boiler efficiency factor at 100 % rating and at medium boiler temperature 70 °C	98.4 % H _i (88.6 % H _s)	98.4 % H _i (88.6 % H _s)	98.4 % H _i (88.6 % H _s)
Boiler efficiency factor at 30 % rating and at return temperature 30 °C	108.8 % H _i (98.0 % H _s)	108.8 % H _i (98.0 % H _s)	108.8 % H _i (98.0 % H _s)
Standby loss at 50 K above room temperature	0.27 % 510 W	0.26 % 583 W	0.25 % 650 W

3 Product description

3.4.10 Dimensions



- ① Safety valve connection 1 1/2"
- ② Gas pipe 1"
- ③ Air inlet pipe DN 110
- ④ Condensate connection
- ⑤ Flue gas connection DN 160
- ⑥ Return 2"
- ⑦ Supply 2"

3.4.11 Weight

	WTC 210	WTC 250	WTC 300
Empty weight	approx. 212 kg	approx. 225 kg	approx. 242 kg

4 Installation

4 Installation




Only valid in Switzerland

When installing and operating in Switzerland the regulations of SVGW, VKF, and local and Cantonal regulations must be observed.

Remove front panel

- Open flap ① on boiler control panel.
- Undo screw ② and remove front panel.




Transport

When transporting, $\frac{3}{4}$ " pipes can be fitted at 6 positions.

When transporting over uneven heights (e. g. stairs) the lower transport points can be used.

- Screw $\frac{3}{4}$ " pipes to the transport points ①.



4 Installation

Installation location

The installation room must comply with local regulations. For must be fitted with an opening leading to atmosphere with a minimum cross section (see DVGW-TRGI, work sheet G 600).

The cross section may be split between a maximum of two openings.

	unit	Minimum cross section
Room air dependent	WTC 120	290 cm ²
	WTC 170	390 cm ²
	WTC 210	470 cm ²
	WTC 250	550 cm ²
	WTC 300	650 cm ²
Room air independent	WTC 120 ... 300	150 cm ² or 2 x 75 cm ²

Dimensions


Observe dimensions when installing the system (see Ch. 3.3.10) or (see Ch. 3.4.10).

Minimum clearances

Leave a clearance of minimum 50 cm between each side of the boiler and walls or other objects.

Adjust boiler position

- Level the boiler horizontally using the 4 screw feet ①.



5 Installation

5 Installation

5.1 Requirements for the heating water



In support of guideline VDI 2035 the following requirements are applicable for heating water.

- Untreated fill and top-up water must be of domestic water quality (colourless, clear and without any sedimentation),
- the fill and top-up water must be pre-filtered (mesh width max 25 µm),
- the pH value must be 8.5 ± 0.5 ,
- there must be no oxygen enrichment of the heating water (max 0.05 mg/l),
- in the case of diffusion resistant system components, the unit must be disconnected from the heating circuit by means of a separator.

5.1.1 Permissible water hardness

The permissible water hardness is determined in proportion to the fill and top up water quantity.

- Determine from the diagram below whether water treatment measures are necessary.

If the fill and top up water lies in the upper range of the limit curves:


- treat the fill and top-up water.

If the fill and top up water lies in the lower range of the limit curves, treatment is not necessary.



- Record the fill and top-up water quantities in a system logbook.

WTC 120 / WTC 170




① Fill and top up water quantity in litres

② Total hardness in °dH

5 Installation

WTC 210 / WTC 250 / WTC 300



① Fill and top up water quantity in litres

② Total hardness in °dH

5.1.2 Fill water quantity

If information about the fill water quantity is not available, the following table can be used to estimate the quantity. On calorifier systems the calorifier content must be taken into consideration.

Heating system	Estimated fill water quantity ⁽¹⁾	
	55/45 °C	70/55 °C
Pipe and steel radiators	37 l/kW	23 l/kW
Cast iron radiators	28 l/kW	18 l/kW
Panel radiators	15 l/kW	10 l/kW
Air conditioning	12 l/kW	8 l/kW
Convectors	10 l/kW	6 l/kW
Underfloor heating	25 l/kW	25 l/kW

⁽¹⁾ based on the heating requirements of the building

5 Installation

5.1.3 Treatment of fill and top-up water

De-ionisation (recommended by Weishaupt)

- ▶ De-ionise the fill and top-up water completely.
(recommendation: mixed bed procedure)

When the heating water has been entirely de-ionised, additional top-up water up to 10% of the system contents may be untreated. Higher quantities of top-up water must be de-ionised.

- ▶ Check the pH value (8.5 ± 0.5) of the de-ionised water:
 - after the commissioning,
 - after 4 weeks of operation,
 - during the annual servicing.
- ▶ If necessary, adjust the pH value of the heating water by the addition of Trisodium Phosphate.

Softening (cation exchanger)



Damage to the appliance due to raised pH value

Softening the water by means of cation exchanger leads to self alkalisation of the heating water. Corrosion can damage the appliance.

- ▶ Following the softening of the water by means of cation exchanger the pH value has to be stabilised

-
- ▶ Soften the fill and top-up water.
 - ▶ Stabilise the pH value.
 - ▶ Check the pH value (8.5 ± 0.5) during the annual servicing.

Stabilisation of hardness



Damage to the appliance due to inappropriate inhibitors

Corrosion and scale could damage the appliance.


- ▶ Only use inhibitors when the manufacturer can guarantee the following:
 - the requirements relating to the heating water are fulfilled,
 - the heat exchanger in the appliance will not be attacked by corrosion,
 - there will be formation of sludge in the heating system.

-
- ▶ Treat the fill and top-up water with inhibitors.
 - ▶ Check the pH value (8.5 ± 0.5) according to the instructions of the inhibitors.

5 Installation

5.2 Hydraulic connection

- ▶ Flush the heating system with at least twice the total system content.
- ✓ Contaminants are removed.
- ▶ Connect the supply and the return (Recommendation: Use shut off valves).
- ▶ Fit safety valves.
- ▶ Fit expansion vessel.
- ▶ If necessary, install a sludge trap in the return line.



- ① Safety valve connection
WTC 120 / WTC 170 = 1 1/4"
WTC 210 / WTC 250 / WTC 300 = 1 1/2"
- ② Supply 2"
- ③ Return 2"
- ④ fill and return tap

Filling the water



Damage to the condensing boiler due to unsuitable fill water

Corrosion and scale could damage the system.

- ▶ Adhere to the requirements for the heating water and the local directives (see Ch. 5.1).

- ▶ Open the shut off valves.
- ▶ Gradually fill the heating system through the inlet tap (system pressure minimum 1.3 bar).
- ▶ Vent the system.
- ▶ Check the system for leakage and check the filling pressure.

5 Installation

5.3 Condensate connection



Danger of poisoning by escaping flue gas

Flue gas can escape if the siphon is not filled.

Inhalation leads to dizziness, nausea and eventually death.

- Check the fill level of the siphon at regular intervals and replenish if necessary, in particular when the system has been shut down for longer periods or has been operated at high return temperatures ($> 55^{\circ}\text{C}$).

The condensate generated during the heating operation is discharged to the house waste water drainage system via an integrated siphon.


Observe work sheet ATV-DVWK-A 251 and install a neutralisation system if required.

If the discharge point of the waste water system is located above the condensate drain:

- Installing condensate lift pump.

Filling the siphon


- Run condensate hose on siphon to condensate outlet pipe.
- Fill siphon with water via the flue gas outlet of the boiler, until water flows from the condensate hose.



If an external siphon ① is present external to the boiler (e. g. due to the condensate hose):

- Cut of cap from ventilation opening.

If there is no external siphon present, the cap must not be removed.



5 Installation

5.4 Gas supply

Only an approved gas installer may carry out the gas side connection. Observe local regulations.

The gas characteristics must match the data given on the name plate of the boiler.

The condensing boiler is factory preset to Natural Gas E (G20).

Gas connection pressure

The gas connection pressure must be within the following ranges:

Natural Gas E/H	17.0 ... 20 ... 25.0 mbar
Natural Gas LL	20.0 ... 25 ... 30.0 mbar

Commissioning outside of the pressure ranges to DIN EN 437 is not permitted.

Installing the gas supply



Risk of explosion due to leaking gas


Gas leaks can lead to a build-up of explosive gas/air mixture. With an ignition source present this can result in an explosion.

- ▶ Install gas supply with care.
- ▶ Observe all safety instructions.

- ▶ Close all shut off devices prior to commencing work and protect from accidental re-opening.
- ▶ Install gas supply pipes tension free.

If a thermal shut off device (TAE) is required:

- ▶ Install a thermal shut off device in front of the gas isolating valve, or install a gas isolating valve with TAE.
- ▶ Install gas isolating valve.
- ▶ Connect gas supply to gas inlet.



Carry out soundness test of gas supply line and vent

Only the gas supply company or a contract installation company may carry out a soundness test and vent the gas line.

5 Installation

5.5 Routing of air/ flue gas circulation

Air supply ducting

The combustion air can be supplied:

- from the installation room (room air dependent operation),
- by connecting an external air inlet duct (room air independent operation).

Flue gas system

Local and building regulations must be observed when designing the flue gas ducting.



CAUTION

Damage to the boiler caused by incorrect flue gas system

The boiler could be overloaded.

- The Boiler should only be commissioned using one of the following boiler connection sets.


The boiler has been certificated with the following boiler connection set, and must only be operated with this set.

WTC 120 / WTC 170:

- Boiler connection set elbow - order number 480 000 11 73 2,
- Boiler connection set straight - order number 480 000 11 74 2.

WTC 210 / WTC 250 / WTC 300:

- Boiler connection set elbow - order number 480 000 11 78 2,
- Boiler connection set straight - order number 480 000 11 79 2.



- Install connection set to flue gas connection (see installation and operating instructions WAL-PP).

Only an approved flue gas system may be used for connection. If the boiler is connected to a chimney, this must be damp proof.

The flue gas system must be sound.

- Carry out a soundness test of the flue gas system.

5 Installation

5.6 Electrical installation



Risk of electric shock

Working on the unit when voltage is applied can lead to electric shock.

- ▶ Isolate unit from mains prior to carrying out work.
- ▶ Safeguard against accidental re-start.


The electrical installation must only be carried out by qualified electricians. Observe local regulations.



Install Bus and external sensor cable separately and preferably using screened cables (metal braiding).

Separate ducts are provided for the separate installation of 230 V cables opposite to Bus and sensor cables (SELV).

- ▶ Feed the cables from the rear of the unit through the cable ducts to the connection box.
- ▶ Assign the inputs and outputs according to application (see Ch. 6.10).
- ▶ Fit screen of Bus and external sensor cable to the designated screen connection terminals.




- ▶ Connect the cables according to the wiring diagram, in the process pay particular attention to the correct phase location of the voltage supply.

5 Installation

5.6.1 Wiring diagram

Observe the instructions for the electrical installation (see Ch. 5.6).

The maximum total current of all external loads must not exceed 4.5 A.




Plug	Colour	Connection	Remarks
230V ↑	Black	Voltage supply 230 V AC / 50 Hz	–
H1	Turquoise	Input 230 V AC/2 mA	–
H2	Red	Input 230 V AC/2 mA	–
MFA 1	Purple	Relay output 230 V AC	max 3 A (AC1)
MFA2	Purple	Relay output 230 V AC	max 3 A (AC1)
VA1	Brown	Potential free relay output	230 V AC/max 3 A (AC1)
eBUS	Light blue	WCM components (FS, EM, KA, COM)	–
B11	White	De-couple sensor NTC 5 kΩ	0 ... 99 °C
B1	Green	External sensor NTC 600 Ω	-40 ... 50 °C
B3	Yellow	DHW sensor NTC 12 kΩ	0 ... 99 °C
▶	Dark blue	Control signal for speed controlled pump 0 ... 10 V	max 20 mA
N1	Orange	Temperature remote control 2 ... 10 V; 4 ... 20 mA	–

5 Installation

5.6.2 Connection additional pump via output VA1

Observe the instructions for the electrical installation (see Ch. 5.6).

► Connect pump to wiring diagram.



6 Operation


6 Operation

6.1 Operating interface

6.1.1 Operating panel

► Open flap.

There are 4 operating elements available.



①	Enter button	Confirm selection, confirm input
②	Dial knob	Navigation through levels and parameters, change values
③	Reset button	Resetting fault conditions. The system will be restarted if there is no fault.
④	Switch S1	System ON/OFF


6 Operation

6.1.2 Display

The display shows the current operating status and operating data.


Symbols are shown or hidden depending on the system variation.

When a remote control is connected (e. g. WCM-FS or WCM-EM) the symbols ⑨ ... ⑪ are not displayed.




- ① Burner in operation
- ② Heating operation is activated
- ③ DHW operation is activated
- ④ Fault
- ⑤ Service note
- ⑥ Flow temperature (standard display); parameters and values
- ⑦ Frost protection is activated
- ⑧ Standby
- ⑨ Summer setting or no heating operation
- ⑩ Heating at night setback value
- ⑪ Heating at setpoint value

Display sensor interruption or short circuit



Display burner rapid cycle interlock (see Ch. 6.7)



6 Operation

6.2 End User Level


In the end user level, various information can be called up and values can be changed.

Symbols are shown or hidden depending on the system variation.

When a remote control is connected (e. g. WCM-FS or WCM-EM) the symbols ① ... ④ are not displayed. If the communication between the electronics and the remote control fails, the symbols for emergency operation are displayed.

6.2.1 Display End User Level

- ▶ Turn the dial knob.
- ✓ Tool bar appears.
- ▶ Turn the dial knob.
- ✓ Selection cursor alternates between the symbols.




- ① Flow temperature(--- = standby)
- ② Flow temperature(--- = standby)
- ③ Type of operation: S = Summer setting, W = Winter setting
- ④ DHW temperature

6 Operation

6.2.2 Settings End User Level

- ▶ Turn the dial knob.
- ✓ Tool bar appears.
- ▶ Turn the dial knob.
- ✓ Selection cursor alternates between the symbols.
- ▶ Press Enter button.
- ✓ Set value will be shown flashing.
- ▶ Change the value with the dial knob and save with Enter button.




	Setting	Range	Factory setting
①	Normal supply temperature setpoint	Setback supply temperature setpoint ... maximum supply temperature (Parameter 31) --- = Standby	60 °C
②	Setback supply temperature setpoint	Minimum supply temperature (Parameter 30) ... normal supply temperature setpoint	30 °C
③	Type of operation	S = Summer W = Winter	W
④	DHW setpoint value	30 °C ... 65 °C --- = DHW operation off	50 °C
⑤	Manual start up chimney sweep function	minimum load ... maximum load	–
⑥	Heating Engineer Level	–	–

6 Operation

6.3 Heating Engineer Level

Activate heating engineer level

- ▶ Turn the dial knob.
- ✓ Tool bar appears.
- ▶ Turn the dial knob and set the selection cursor below the spanner symbol.
- ▶ Press Enter button.
- ▶ Turn the dial knob and set code 11.
- ▶ Confirm setting with the enter button.
- ✓ Heating engineer level tool bar will appear.



- ① Info level
- ② Parameter level
- ③ Fault history

- ▶ Turn the dial knob and set the selection cursor below the required level.
- ▶ Press Enter button.
- ✓ Level will be activated.

Exit heating engineer level

- ▶ Turn the dial knob until ESC appears.
- ▶ Press Enter button.




6 Operation

6.3.1 Info level

Display system values (i)

- ▶ Activate info level (see Ch. 6.3).
- ▶ Turn the dial knob.
- ✓ System values can be read.

Depending on system variation, specific values are shown or hidden.



Info	system	Unit
i 10	Operating phase 0 = Burner off 1 = Standby check fan 2 = Prepurge speed achieved 3 = Prepurge 4 = Ignition speed achieved 5 = Ignition Flame formation time (10 ± 1.0 seconds) 6 = Burner in operation 7 = Gas valve check 8 = Post purge speed achieved and post purge	–
i 11	Rating	%
i 12 ⁽¹⁾	average external temperature	°C
i 13	Single boiler = Flow setpoint value Cascade operation = Ratings setpoint value Remote operation DDC = temperature setpoint value Remote operation WCM-FS, WCM-EM, via N1 = peak heat demand	°C % °C °C
i 15	Temperature setpoint value via N1	°C

⁽¹⁾ can be reset

Info	Actuators	Unit
i 20	Type of operation H = Heating operation W = DHW	–
i 22	Pump rating	%
i 23	Fan speed	rpm x 10

Info	Sensors	Unit
i 30	eSTL temperature	°C
i 31	Flue gas temperature	°C
i 32	Ionisation signal Setpoint minimum rating: 9 ... 16 µA Setpoint maximum rating: 10 ... 20 µA Limit value: 4 µA	µA
i 33	External temperature	°C
i 34	DHW temperature	°C
i 35	Supply temperature	°C

6 Operation

Info	Sensors	Unit
i 37	Return temperature	°C
i 39	De-couple sensor temperature	°C
Info	System info	Unit
i 42	Burner starts	x 1000
i 43	Burner operating hours	h x 100
i 44	Software version WCM-CPU	–
i 45	Software version WCM-CUI	–
i 46 ⁽¹⁾	Time since last servicing	h x 10
i ESC	Exit menu	–

⁽¹⁾ can be reset

Reset system values

- Press enter button for 2 seconds.
- ✓ Values will be reset.


6 Operation

6.3.2 Parameter level

Show parameter (P)

- ▶ Activate parameter level (see Ch. 6.3).
- ▶ Turn the dial knob.
- ✓ Parameters can be read.

Depending on system variation, specific parameters are shown or hidden.



Changing values

- ▶ Press Enter button.
- ✓ Set value will be shown flashing.
- ▶ Change the value with the dial knob.
- ▶ Save the value with the enter button.

Parameters	Basic configuration	Range of values	Factory setting
P 10	Unit configuration	(see Ch. 7.2)	–
P 11	Type of gas	E = Natural Gas EA = Natural Gas with flue gas damper (set P 13 = 9, P 16, 17 = 4)	E
P 12	Boiler address	1 = Single unit A = 1st unit of cascade, DDC System (set P 71 = 1) B ... E = Consecutive units of cascade, DDC System (set P 71 = 0)	1
P 13	Function variable output MFA1	0 = Forward reporting of operation 1 = Forward reporting of lockout 2 = Pump (heating and DHW operation) 3 = Heating circuit pump (heating operation) 4 = DHW load pump (DHW operation) 6 = DHW circulation pump via WCM-FS 7 = Heating circuit pump via WCM-FS #1, #1+2 8 = Permanent voltage 9 = Activation flue gas damper (fixed, when P 11 = EA)	2
P 14	Function variable output MFA 2	0 = Forward reporting of operation 1 = Forward reporting of lockout 2 = Pump (heating and DHW operation) 3 = Heating circuit pump (heating operation) 4 = DHW load pump (DHW operation) 6 = DHW circulation pump via WCM-FS #1, #1+2, #2 7 = Heating circuit pump via WCM-FS #1, #1+2 8 = Permanent voltage	3
P 15	Function variable output VA1	0 = Forward reporting of operation 1 = Forward reporting of lockout 2 = Pump (heating and DHW operation) 3 = Heating circuit pump (heating operation) 4 = DHW load pump 6 = DHW circulation pump via WCM-FS #1, #1+2, #2 7 = Heating circuit pump via WCM-FS #1, #1+2	4

6 Operation

Parameters	Basic configuration	Range of values	Factory setting
P 16	Function input H1	0 = Heating circuit release 1 = Heating circuit setback/normal 3 = Standby with frost protection 4 = Return signal flue gas damper (fixed, when P 11 = EA)	1
P 17	Function input H2	0 = DHW release 2 = Heating operation with special level 3 = Burner lockout function 4 = Return signal flue gas damper (fixed, when P 11 = EA)	0
P 18	Special level heating operation (only when P 17 = 2)	8 °C ... P 31	60
Parameters	Weather compensation	Range of values	Factory setting
P 20	External sensor adjustment	-4 ... 4 K	0
P 23	System frost protection (see Ch. 6.9)	-10 ... 10 °C	5
Parameters	Heat exchanger	Range of values	Factory setting
P 30	Minimum supply temperature	8 °C ... (P 31 - P 32)	8
P 31	Maximum supply temperature	(P 30 + P 32) ... (85 °C - P 32)	79
P 32	Switching differential supply temperature	+1 ... 7 K	4
P 33	Switch-off temperature flue gas duct	80 ... 120 °C	120
P 34	Burner rapid cycle interlock	1 ... 15 min --- = deactivation	5
P 35	Ignition speed	30 ... 45 %	WTC 120=38 WTC 170=37 WTC 210=38 WTC 250=37 WTC 300=31
P 36	Minimum load	WTC 120=25 % ... P 37 WTC 170=22 % ... P 37 WTC 210=26 % ... P 37 WTC 250=23 % ... P 37 WTC 300=22 % ... P 37	WTC 120=25 WTC 170=22 WTC 210=26 WTC 250=23 WTC 300=22
P 37	Maximum load heating operation	P 36 ... 100 %	100
P 38	Maximum load DHW	P 36 ... 100 %	100


6 Operation

Parameters	Circulation pump	Range of values	Factory setting
P 40	Pump operation mode heating	0 = pump run-on 1 = pump continuous run	0
P 41	Pump run-on time heating operation (only when P 40 = 0)	1 ... 60 min	10
P 42	Pump run-on time DHW Deactivation	1 ... 10 min ---	3
P 43	Function speed controlled pump (see Ch. 6.8.2)	--- = No speed controlled pump 1 = Rating pump ~ rating WTC 2 = Rating pump ~ interconnection between supply and return temperature (temperature differential control) or 2 = Rating pump ~ interconnection between supply and de-couple temperature (de-couple control)	---
P 44	Minimum load speed controlled pump heating	20 % ... P 45	20
P 45	Maximum load speed controlled pump heating	P 44 ... 100 %	100
P 46	Load speed controlled pump in DHW operation	20 ... 100 %	100
P 47	Optimisation de-couple control Supply / de-couple temperature (only when P 43 = 2)	1 ... 7 K	2
P 48	Optimisation temperature differential control Supply / return temperature (only when P 43 = 2)	10 ... 22 K	20
P 49	Idleness temperature differential control	1 ... 62 s	4
Parameters	Hot water	Range of values	Factory setting
P 50	Temperature increase during DHW operation	10 ... 30 K	10
P 51	Switching differential DHW	-3 ... -10 K	-5
Parameters	System + Servicing	Range of values	Factory setting
P 70	Service interval	100 ... 500 h x 10 --- = deactivation	400
P 71	eBus feed (only when P 12 = A ... E)	0 = not activated 1 = activated	1
ESC	Exit menu	—	—

6 Operation

6.4 Manual start up


- ▶ Turn the dial knob.
- ✓ Tool bar appears.
- ▶ Set the selection cursor below the chimney sweep symbol.
- ▶ Press Enter button.
- ✓ Maximum rating is started.



① Supply temperature

② Rating in %

- ▶ Press Enter button.
- ▶ Set the required rating with the dial knob.
- ✓ The started rating remains active for 15 minutes.



The burner automatically reduces the rating, when the flow temperature approaches the maximum flow temperature (parameter 31).

Exit manual ratings setting

- ▶ Press Enter button.
- ✓ You will exit manual ratings setting.
- ✓ The last rating set will remain activated for 2 minutes.



The time sequence of 2 minutes can be restarted by turning the dial knob in the heating engineer level within these 2 minutes. This provides the possibility of calling up system values in the info level at the relevant rating.

Display system values

- ▶ Activate info level (see Ch. 6.3).
- ✓ System values of the most recently set rating can be displayed.

6 Operation


6.5 Start manual configuration

Manual configuration is used to match the settings with unit version. All sensors and actuators are re-entered during this process (see Ch. 7.2).

- ▶ Activate parameter level (see Ch. 6.3).
- ▶ Select parameter 10.
- ✓ Current configuration appears.
- ▶ Press Enter button.
- ▶ Turn the dial knob until --- appears.
- ▶ Press Enter button.
- ✓ New configuration is located and displayed.
- ▶ Press Enter button.
- ✓ The configuration is stored.

Example

External sensor has been removed.



6 Operation

6.6 Control options

Constant flow temperature control

No additional sensors or thermostats are required for this control. The flow temperature is controlled at the value set in the end user level (see Ch. 6.2.2).

Weather compensation

A remote control station (WCM-FS) and an external sensor (QAC 31) are required for weather compensated control.

- Mount the external sensor to the north side or the north-west side of the building, half way up (min 2.5 m).

Avoid direct solar radiation and heat up by external heat sources.

- If necessary carry out a temperature adjustment of the external sensor via parameter 20.

DHW operation

DHW operation takes priority over the heating operation.

DHW preparation is carried out when the temperature in the water heater drops below the DHW setpoint value minus switch differential (parameter 51).

6.7 Control options


Heating operation with special level

This function is also effective in the Summer setting.

- Set parameter 17 at 2.


When contact H2 is closed, the system heats up to the temperature level preset in parameter 18. Higher setpoint values of additional heating circuits will be taken into account. DHW preparation generally takes priority. If the contact is open, the temperature will be defined according to the control variation available.

When the heating operation with special level is activated, S_n and the current flow temperature will be displayed.



Dynamic burner rapid cycle interlock

The dynamic burner rapid cycle interlock prevents the burner from starting too often. It functions depending on certain boiler temperatures and cannot be deactivated. It is independent of parameter 34.



6 Operation

Temperature remote control 2 ... 10 V

- Connect analogue setpoint signal 2 ... 10 V to input N1 (see Ch. 5.6.1).
- ✓ Signal is interpreted as supply setpoint.

3 V	Minimum flow temperature (P 30)
10 V	Maximum flow temperature (P 31)
2 ... 3 V	Burner off
<2 V	Signal fault (after ca. 15 minutes W89)

A maximum of six extension modules (WCM-EM) can be installed if a control signal is connected at input N1.

Temperature remote control 4 ... 20 mA

It is possible to use input N1 as current input 4 ... 20 mA. To do this, a switchover must be made via a jumper on the circuit board.




Risk of electric shock


Working on the unit when voltage is applied can lead to electric shock.

- Isolate unit from mains prior to carrying out work.
- Safeguard against accidental re-start.

- Switch off system.
- Remove housing cover from connection box.



- Change over red jumper ① on circuit board.



6 Operation

6.8 Boiler circuit pump

6.8.1 General information

The unit can drive an external boiler circuit via outputs MFA 1, MFA 2 or VA1.

The pump remains activated as long as heat requirement prevails. When no more heat is needed, the pump runs for the specified run-on time (NLZ) preset in parameter 41.

Continuous pump operation can be set with parameter 40, if this is required.

Pump control logic

Type of operation	Standby/ Summer			
Control option	with external sensor		without external sensor	
Setting P 40	1	0	1	0
Pump operation	NLZ, OFF	NLZ, OFF	Continuous operation	NLZ, OFF

Type of operation	Winter			
Control option	with external sensor		without external sensor	
Setting P 40	1	0	1	0
Pump operation	Continuous operation	NLZ, OFF ⁽¹⁾	Continuous operation	Continuous operation

⁽¹⁾ Function in setback operation. In normal operation, the pump runs continuously and independently of P 40.

6.8.2 Speed controlled pump

If a speed controlled pump is used, the control is carried out via a 0 ... 10 V control signal.

- Connect control signal at plug (see Ch. 5.6.1).

Standard control

Here, the pump rating is assigned to the required burner load. The pump is operated at minimum load when the burner is switched off.

- Set parameter 43 to 1.
- Set the modulation limits for the pump via parameter 44 and 45.
- Set the modulation limit for the pump in DHW operation via parameter 46.

Temperature differential control

With this control option, the pump modulates the temperature differential between supply sensor and return sensor.

- Set parameter 43 to 2.
- Set temperature differential via parameter 48.

De-couple control

With this control option, the pump modulates between the decouple sensor and the supply sensor depending on the temperature differential. The control differential can be matched to system specific requirements using parameter 47.

- Set parameter 43 to 2.
- Connect de-couple sensor to input B11.

6 Operation

6.9 Frost protection

Boiler frost protection

Flow temperature $< 8^{\circ}\text{C}$

- Burner is operated at minimum load.
- Outputs MFA and VA are active, if they have been parametered as heating circuit pump or feeder pump.

Flow temperature $> 20^{\circ}\text{C}$:

- Burner switches off,
- Pump run-on is activated (parameter 41).

System frost protection (with external sensor)

External temperature $<$ system frost protection (parameter 23) minus 5 Kelvin:

- Outputs MFA and VA are active, if they have been parametered as heating circuit pump or feeder pump,
- load pumps on eBus are active,
- thermal protection via boiler frost protection.

External temperature $>$ system frost protection (parameter 23):

Pump continuous run is deactivated.

DHW frost protection (version W)

DHW temperature $< 8^{\circ}\text{C}$

- Burner is operated at minimum load.
- Outputs MFA and VA are active, if they are parametered as feeder pump, DHW load pump or circulation pump.

DHW temperature $> 8^{\circ}\text{C}$ plus half the DHW switch differential (parameter 51):

- Burner switches off,
- Pump run-on is activated (parameter 42).

During DHW frost protection, the tap symbol flashes in the display.

6 Operation

6.10 Inputs and outputs

Different applications can be realised with the freely selectable inputs and outputs.

Output MFA and VA

Output MFA is a non-isolated relay output. Output VA is potential free.

All relay outputs can have a maximum loading of 3 A (AC1). The maximum total current from all external loads must not exceed 4.5 A.

Setting parameters 13, 14, 15	Description
0 = forward reporting of operation	The contact closes as soon as heat demand is present or if the gas supply is insufficient.
1 = Forward reporting of lockouts and warnings	The contact closes as soon as a fault occurs or when a warning is triggered for at least 4 minutes.
2 = external feeder pump	The output is activated in the same way as an internal heating circuit pump (for heating and DHW).
3 = External heating circuit pump	The output is activated during heating operation.
4 = DHW load pump	The output is activated during DHW operation.
6 = DHW circulation pump via WCM-FS	The output is activated depending on the WCM-FS.
7 = Heating circuit pump via WCM-FS	Single unit (parameter 12 = 1) The output is activated when heating operation is requested by the WCM-FS. When there is no longer a demand for heat, the pump runs on for 3 minutes. The output is deactivated immediately DHW loading is carried out (DHW priority). Cascade (parameter 12 = A ... E) The output is activated by the cascade manager.
8 = Permanent voltage (only parameters 13, 14)	The output is permanently active.
9 = Flue gas damper (only parameter 13)	The output is activated prior to burner start to open the flue gas damper.

Input H1

Setting parameter 16	Description
0 = Release of heat exchanger in heating operation	The release is given for heating operation when the input is closed. The WTC is disabled for heating operations when the input is open.
1 = Heating circuit setback / normal	The normal setpoint is effective when the input is closed. The setback value is effective when the input is open.
3 = Standby with frost protection	The system is in standby when the input is closed. The operating modes DHW and heating are disabled. Frost protection is activated. Systems with external WCM-FS or WCM-EM heating circuits are also disabled.
4 = Return signal flue gas damper open	Burner start is only released once the flue gas damper is open and a return signal has been sent to H1.

Input H2

Setting parameter 17	Description
0 = Release of heat exchanger in DHW operation	The release for DHW is given when the input is closed. The WTC is disabled for hot water operation when the input is open.
2 = Heating operation with special level	(see Ch. 6.7)

6 Operation

Setting parameter ¹⁷	Description
3 = Burner lockout function	If the input is closed, both the appliance and the pump switch off. Frost protection is not active. The display shows $\overline{W}24$, when the contact is closed. This function can be used for example to connect a safety switch for a condensate lift device.
4 = Return signal flue gas damper closed	When the flue gas damper is closed, a return signal is sent to H2.

6 Operation

6.11 Special system parameters

6.11.1 System parameters WTC 120 / WTC 170

System parameters can be set in the heating engineer level. In rare cases it may be necessary to more closely adapt the WTC to the heating system using the WCM Diagnostic Software. For further information see the Software Operating Instructions.



For remote control with WCM-FS, the eBus adapter WEA must be supplied with voltage via separate mains adapter.

Desc.	Parameters	Range of values	Unit	WTC 120 ⁽¹⁾	WTC 170 ⁽¹⁾
A1	HC and DHW controller P Part	1 ... 255		10	10
A2	HC and DHW controller I Part	1 ... 255		2	2
A4	Fan controller P Part	1 ... 255	x 0.25	7	10
A5	Fan controller I Part	1 ... 255	x 0.125 s	5	8
A6	Fan controller adjustment	0 ... 15		1	1
A7 ⁽²⁾	Fan controller start PWM	15 ... 30	%	15	15
A10	Max fan speed boiler	WTC 120 = 5280 ... 5760 WTC 170 = 5460 ... 5940	rpm	5520	5700
A11	Max speed change (modulating up)	60 ... 360	rpm/s	60	60
A12	Max speed change (modulating down)	60 ... 360	rpm/s	120	120
A13	Max speed change (modulating down after burner start)	30 ... 360	rpm/s	60	60
A14	Rating delayed heating operation	WTC 120 = 25 ... 100 WTC 170 = 22 ... 100	%	25	22
A15	Duration delayed heating operation	0 ... 5	min	1	1
A21 ⁽²⁾	Max temperature spread Flow B12/return B13	20 ... 40	K	40	40
A22 ⁽²⁾	Max temperature spread Flow eSTL/B12	20 ... 25	K	25	25
A23 ⁽²⁾	Max temperature gradient eSTL (0 = no monitoring)	0.5 ... 2.0	K/s	2.0	2.0
A31	Max run time flue gas damper	15 ... 35	s	25	25
A32	PWM setpoint pump inverse	0 / 1	–	0	0

⁽¹⁾ Factory setting.

⁽²⁾ Parameter is safety relevant. Alterations are only permitted following consultation with the Weishaupt service department.

6 Operation

6.11.2 System parameters WTC 210 / WTC 250 / WTC 300

System parameters can be set in the heating engineer level. In rare cases it may be necessary to more closely adapt the WTC to the heating system using the WCM Diagnostic Software. For further information see the Software Operating Instructions.



For remote control with WCM-FS, the eBus adapter WEA must be supplied with voltage via separate mains adapter.

Desc	Parameters	Range of values	Unit	WTC 210 ⁽¹⁾	WTC 250 ⁽¹⁾	WTC 300 ⁽¹⁾
A1	HC and DHW controller P Part	1 ... 255		10	10	10
A2	HC and DHW controller I Part	1 ... 255		2	2	2
A4	Fan controller P Part	1 ... 255	x 0.25	8	8	10
A5	Fan controller I Part	1 ... 255	x 0.125 s	13	13	12
A6	Fan controller adjustment	0 ... 15		1	1	1
A7 ⁽²⁾	Fan controller start PWM	15 ... 30	%	21	21	18
A10	Max fan speed boiler	WTC 210 = 5340 ... 5820 WTC 250 = 5280 ... 5760 WTC 300 = 5940 ... 6420	rpm	5580	5520	6120
A11	Max speed change (modulating up)	60 ... 360	rpm/s	60	60	60
A12	Max speed change (modulating down)	60 ... 360	rpm/s	120	120	120
A13	Max speed change (modulating down after burner start)	30 ... 360	rpm/s	60	60	60
A14	Rating delayed heating operation	WTC 210 = 26 ... 100 WTC 250 = 23 ... 100 WTC 300 = 22 ... 100	%	26	23	22
A15	Duration delayed heating operation	0 ... 5	min	1	1	1
A21 ⁽²⁾	Max temperature spread Flow B12/return B13	20 ... 40	K	40	40	40
A22 ⁽²⁾	Max temperature spread Flow eSTL/B12	20 ... 25	K	25	25	25
A23 ⁽²⁾	Max temperature gradient eSTL (0 = no monitoring)	0.5 ... 2.0	K/s	2.0	2.0	2.0
A31	Max run time flue gas damper	15 ... 35	s	25	25	25
A32	PWM setpoint pump inverse	0 / 1	–	0	0	0

⁽¹⁾ Factory setting.


⁽²⁾ Parameter is safety relevant. Alterations are only permitted following consultation with the Weishaupt service department.

6 Operation

6.12 Chimney sweep function

Activate chimney sweep function

- ▶ Turn the dial knob.
- ✓ Tool bar appears.
- ▶ Set the selection cursor below the chimney sweep symbol.
- ▶ Press Enter button.
- ✓ The chimney sweep function remains active for 15 minutes.




① Supply temperature

② Rating in %

Deactivate chimney sweep function.

- ▶ Turn the dial knob.
- ✓ ESC appears.
- ▶ Press Enter button.
- ✓ Chimney sweep function is deactivated.



The standard display re-appears after approx. 90 seconds.

7 Commissioning

7 Commissioning

7.1 Prerequisite

Commissioning must only be carried out by qualified personnel.

Only correctly carried out commissioning ensures the operational safety of the unit.

- ▶ Prior to commissioning check:
 - All installation work must be completed and checked prior to commissioning.
 - Electrical installation duly completed, electric circuits duly fused and measures for contact protection of electrical components and of all wiring checked.
 - Boiler and heating system have been adequately filled with water and vented.
 - Siphon has been filled.
 - An adequate supply of fresh air is guaranteed.
 - The flue gas ducts and combustion air ducts are unimpeded.
 - All regulating, control and safety devices are functioning and set correctly.
 - Heat demand is ensured.

Additional system-related tests could be necessary. Please observe the operating guidelines for the individual components.

7 Commissioning

7.1.1 Check soundness of gas valve train

Soundness test

- ▶ Carry out soundness test:
 - prior to commissioning,
 - after all service and maintenance work.
- ▶ Switch off system.
- ▶ Close gas isolating valve.
- ▶ Open screw on test point Pe ① of the gas combi valve.
- ▶ Connect test equipment to Pe.
- ▶ Generate test pressure of 100 ... 150 mbar.
- ▶ Wait for pressure equalisation for 5 minutes.
- ▶ Initiate a test period of 5 minutes.
- ▶ Check pressure loss.
- ✓ The gas section is sound, if the pressure does not drop by more than 1 mbar.




Risk of explosion due to leaking gas

Improper service work can lead to escaping gas and explosion.

- ▶ Tightly close the screws on the test points following work on the gas combi valve.

- ▶ Document result of the soundness test on the engineers report.



7 Commissioning

7.1.2 Check gas connection pressure

The gas connection pressure must be within the following ranges:

Natural Gas E/H	17.0 ... 20 ... 25.0 mbar
Natural Gas LL	20.0 ... 25 ... 30.0 mbar

- ▶ Open screw on test point Pe the gas combi valve (see Ch. 7.1.1).
- ▶ Connect pressure measuring device.
- ▶ Slowly open isolating valve whilst checking the pressure increase.

If the measured connection pressure exceeds 60 mbar:

- ▶ Immediately close isolating valve.
- ▶ Do not start plant.
- ▶ Inform system operator.

If the measured connection pressure is insufficient:

- ▶ Do not start plant.
- ▶ Inform system operator.



Risk of explosion due to leaking gas

Improper service work can lead to escaping gas and explosion.

- ▶ Tightly close the screws on the test points following work on the gas combi valve.

Due to the pressure loss in the gas supply, it is possible that the minimum gas pressure at test point Pe during operation (maximum rating) is less than the gas connection pressure.

	Natural Gas E/H	Natural Gas LL	Natural Gas LL
Gas isolating valve	1"	1"	1 1/4"
WTC 120	16 mbar	18 mbar	–
WTC 170	16 mbar	18 mbar	–
WTC 210	15 mbar	17 mbar	–
WTC 250	15 mbar	–	16 mbar
WTC 300	14 mbar	–	15 mbar

7 Commissioning


7.2 Adjusting the boiler

- During commissioning check:
 - Maximum possible water throughput is ensured.
 - Heat up is carried out with low flow temperatures and at low rating.
 - Operate all boilers on multi boiler systems at the same time at low rating.
 - Gas connection pressure at maximum rating within the value given (see Ch. 7.1.2).

1. Configuring the system

- Close gas isolating valve.
- Switch on system at switch S1 (see Ch. 6.1.1).

On activation of the voltage supply the WTC recognises the boiler type, all connected sensors and actuators. The recognised configuration is indicated by a flashing display every 30 seconds.



①	Unit type	12 = WTC 120 17 = WTC 170 21 = WTC 210 25 = WTC 250 30 = WTC 300 P3 = De-couple sensor ⁽¹⁾
②	Version	H = heating operation W = heating operation and DHW operation
③	External sensor	A = external sensor - = no external sensor

⁽¹⁾ If a de-couple sensor has been fitted P3 will be displayed after approx. 7 seconds.

- Press Enter button.
- ✓ The configuration is stored.



The display shows W47 because the gas isolating valve is closed.

If the enter button is not activated within 30 seconds, the configuration will be stored automatically after 24 hours. The configuration can also be started manually (see Ch. 6.5). A configured boiler indicates the saved configuration whenever the power supply is switched on.

The boiler must be reconfigured if sensors or actuators are replaced (see Ch. 6.5). Automatic configuration is only performed during the initial commissioning.

2. Set parameters

- Activate parameter level (see Ch. 6.3).
- Select individual parameters and adapt to the requirements of the system.

7 Commissioning

3. Adjust combustion

The boiler is factory preset for operation with Natural gas E, H (G20).

The O₂ content must be checked and if necessary adjusted.

WTC 120

Set O₂ content at maximum rating


- ▶ Open gas isolating valve.
- ▶ Manually drive rating to maximum (see Ch. 6.4).
- ▶ Check combustion and if necessary adjust.
- ▶ Set O₂ content at setting screw ① as per table:
 - Clockwise rotation = O₂ content increases
 - Anticlockwise rotation = O₂ content decreases



The setting screw for maximum rating has no stop. If it is turned too much, the O₂ adjustment will be in the opposite direction.

Set O₂ content at minimum rating.

- ▶ Manually drive rating to minimum (see Ch. 6.4).
- ▶ Check combustion and if necessary adjust.
- ▶ Remove closing cover ③ from gas combi valve.
- ▶ Set O₂ content at setting screw ② as per table:
 - Anticlockwise rotation = O₂ content increased
 - Clockwise rotation = O₂ content reduces



	O ₂ minimum rating	O ₂ maximum rating
Natural Gas	4.6 % ±0.2	4.3 % ±0.2

7 Commissioning


WTC 170 / WTC 210 / WTC 250 / WTC 300

Set O₂ content at maximum rating

- ▶ Open gas isolating valve.
- ▶ Manually drive rating to maximum (see Ch. 6.4).
- ▶ Check combustion and if necessary adjust.
- ▶ Remove closing cover ② from gas combi valve.
- ▶ Set O₂ content at setting screw ① as per table:
 - Clockwise rotation = O₂ content increases
 - Anticlockwise rotation = O₂ content decreases

Set O₂ content at minimum rating.

- ▶ Manually drive rating to minimum (see Ch. 6.4).
- ▶ Check combustion and if necessary adjust.
- ▶ Remove screwed plug ③ from gas combi valve.
- ▶ Set O₂ content at setting screw ④ as per table:
 - Anticlockwise rotation = O₂ content increased
 - Clockwise rotation = O₂ content reduces



	O ₂ minimum rating	O ₂ maximum rating
Natural Gas	4.6 % ±0.2	4.3 % ±0.2

4. Concluding work



Risk of explosion due to leaking gas

Improper service work can lead to escaping gas and explosion.

- ▶ Tightly close the screws on the test points following work on the gas combi valve.

- ▶ Recheck O₂ content at maximum and minimum rating and optimise if necessary.
- ▶ Close the test points and replace covers.
- ▶ Enter combustion values and settings in the commissioning record.
- ▶ Inform the operator about the use of the equipment.
- ▶ Hand the installation and operating manual to the operator and inform him that this must be kept on site.
- ▶ The operator should be told that the installation must be serviced annually.

If the type of gas is different to the factory set type:

- ▶ Apply the enclosed sticker for type of gas and gas pressure.

7 Commissioning

7.3 Calculate combustion heat rating

V_B	Operating volume in m ³ /h (gas throughput)
V_N	Normal volume in m ³ /h (gas throughput at 0 °C and 1013 mbar)
V_G	Gas throughput determined at gas meter
T_M	Time measured during gas throughput determination (V_G)
f	Conversion factor
t_{Gas}	Gas temperature at meter in °C
P_{Gas}	Gas pressure at meter in mbar
P_{Baro}	Barometric air pressure in mbar (see table)
Q_F	Combustion heat rating in kW
H_i	Calorific value in kWh/m ³ (at 0 °C and 1013 mbar)

Determine operating volume (gas throughput)

- Measure gas throughput (V_G) at gas meter, measuring time (T_M) should be a minimum of 60 seconds.
- Calculate operating volume (V_B) using the following formula.

$$V_B = \frac{3600 \cdot V_G}{T_M}$$

Calculate conversion factor

- Determine gas temperature (t_{Gas}) and gas pressure (P_{Gas}) at gas meter.
- Determine air pressure (P_{Baro}) from the following table.

Height above sea level (m)	0	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300
P_{Baro} in mbar	1013	1001	990	978	966	955	943	932	921	910	899	888	877	866

- Calculate conversion factor (f) using the following formula.

$$f = \frac{P_{Baro} + P_{Gas}}{1013} \cdot \frac{273}{273 + t_{Gas}}$$

Calculate normal volume

- Calculate normal volume (V_N) using the following formula.

$$V_N = V_B \cdot f$$

Calculate combustion heat rating

- Calculate combustion heat rating (Q_F) using the following formula.

$$Q_F = V_N \cdot H_{i,n}$$

8 Shutdown

8 Shutdown

For breaks in operation:

- ▶ Switch off appliance.
- ▶ Close fuel shut off devices.
- ▶ If there is a risk of frost drain system.

9 Servicing

9 Servicing



Risk of explosion due to leaking gas

Improper service work can lead to escaping gas and explosion.

- ▶ Close fuel shut off devices prior to starting work.
- ▶ Care should be taken when dismantling and assembling gas carrying system components.
- ▶ Tightly close the screws on the test points.



Risk of electric shock

Working on the unit when voltage is applied can lead to electric shock.

- ▶ Isolate unit from mains prior to carrying out work.
- ▶ Safeguard against accidental re-start.



Danger of poisoning by escaping flue gas

Flue gas can escape if the siphon is not filled.

Inhalation leads to dizziness, nausea and eventually death.

- ▶ Check the fill level of the siphon at regular intervals and replenish if necessary, in particular when the system has been shut down for longer periods or has been operated at high return temperatures ($> 55^{\circ}\text{C}$).



Danger of getting burned on hot components

Hot components can lead to burns.

- ▶ Allow components to cool.

Servicing must only be carried out by qualified personnel. The combustion plant should be serviced annually. Depending on site conditions more frequent checks may be required. During the service, all system components with high wear and tear or with a specific life span should be replaced.



Weishaupt recommends a service contract is entered into to ensure regular inspections.

Repair work on the following components must only be carried out by the component manufacturer or their approved agent:

- printed circuit board (WCM-CPU),
- gas combi valve,
- pressure switch,
- safety valve.

Prior to every servicing

- ▶ Inform operator.
- ▶ Switch off mains switch of installation and safeguard against accidental reactivation.
- ▶ Close fuel shut off devices.
- ▶ Remove front panel (see Ch. 4).



- ▶ Carry out servicing in accordance with the enclosed inspection card (Print No. 7570).

9 Servicing

Following servicing

- ▶ Check soundness of gas valve train (see Ch. 7.1.1).
- ▶ Check soundness of flue gas and condensate carrying components.
- ▶ Check tightness of water carrying components.
- ▶ Check tightness of burner flange/fan connection and burner flange/heat exchanger connection.
- ▶ Check combustion values and O₂ content, if necessary re-adjust.
- ▶ Enter combustion values and settings in the commissioning record.
- ▶ Refit front panel.

9 Servicing

9.1 Safety components

- Vital safety components must be replaced as soon as they reach their predefined lifetime.

The predefined lifetime is not the warranty time specified in the terms and conditions of delivery and payment.

Safety component	Lifetime according to construction	CEN-Standard
Printed circuit board (WCM-CPU)	10 years or 250 000 operating cycles	EN 298-2003
Gas combi valve	500 000 operating cycles	EN 126-1993
Gas pressure switch	500 000 operating cycles	EN 1854-1997
Air pressure switch	1 000 000 operating cycles	EN 1854-1997
Flue gas pressure switch	1 000 000 operating cycles	EN 1854-1997
O ring Burner flange/fan	10 years	EN 549 H3/B1
O ring 33 x 2 Gas valve/gas connection piece WTC 120	10 years	EN 549 H3/B1
O ring 52.39 x 3.53 Gas valve/gas connection piece WTC 170 ...300	10 years	EN 549 H3/B1
Safety valve 3 bar	10 years	TRD 721-1997

9.2 Servicing display


The time interval to the next service can be set. A flashing spanner will appear in the display when the set interval has expired. **Servicing** is displayed, if a remote control station is used.

Setting the service interval

- Activate parameter level (see Ch. 6.3).
- Set service interval via parameter 70.

Resetting the service display

The service display ① must be reset after servicing.




- Activate info level (see Ch. 6.3).
- Select 46 in Info level i.
- Press enter button for 2 seconds.
- ✓ Service display and timer will be reset.

9 Servicing

9.3 Check differential pressure at air pressure switch

Observe notes on servicing (see Ch. 9).

- ▶ Remove right side panel.
- ▶ Remove hoses from the test points ① on the air pressure switch.
- ▶ Connect test equipment:
 - + to P1,
 - - to P2.



During testing the maximum heating operation rating (parameter 37) must be set 100 %.

- ▶ Switch on main switch.
- ▶ Check parameter 37, if necessary set to 100 %.
- ▶ Manually drive to rating (see Ch. 6.4).
- ▶ Set the following ratings depending on the type of boiler:

Type of boiler	Rating in %
WTC 120	40
WTC 170	45
WTC 210	45
WTC 250	43
WTC 300	37

- ▶ Read differential pressure from measuring device.

If the pressure is above 1.2 mbar the test is ok.

If the pressure is lower:

- ▶ Check the following components:
 - Hoses of the air pressure switch
 - Burner tube for soiling
 - Heat exchanger for soiling
 - Air and flue gas ducting unimpeded
- ▶ If necessary reset parameter 37 after testing.


9 Servicing

9.4 Replacing electrodes

Observe notes on servicing (see Ch. 9).


Ignition electrode

- ▶ Remove ignition plug ⑤ and earth wire ③ with a slightly twist.
- ▶ Remove bolts ④.
- ▶ Replace ignition electrode ② and gasket ①, whilst observing the ignition electrode distance of 4.0 mm.



Ionisation electrode

- ▶ Remove plug (X14) ④ and earth wire ⑤ from boiler electronics.
- ▶ Remove bolts ②.
- ▶ Replace ionisation electrode ③ and gasket ①.




9 Servicing

9.5 Removing and refitting burner tube


Observe notes on servicing (see Ch. 9).

Removal WTC 120

- ▶ Close gas isolating valve.
- ▶ Remove electrodes (see Ch. 9.4).
- ▶ Remove plugs for gas pressure switch ⑤, gas valve ④ and fan ②.
- ▶ Undo screwed union ③ on gas pipe, counter holding with a spanner.
- ▶ Remove nuts ① on burner flange.
- ▶ Remove hoses on gas/air interconnection.




- ▶ Remove burner flange with gas/air interconnection ③.
- ▶ Remove gasket on burner flange ②.
- ▶ Remove burner tube ①.
- ▶ Remove deposits from combustion chamber.
- ▶ Check burner tube for visible damage, replace if necessary.




9 Servicing

Removal WTC 170 / WTC 210 / WTC 250 / WTC 300

- ▶ Close gas isolating valve.
- ▶ Remove electrodes (see Ch. 9.4).
- ▶ Remove plugs for gas pressure switch ⑥, gas valve ⑤ and fan ②.
- ▶ Undo screwed union ④ on gas pipe, counter holding with a spanner.
- ▶ Remove nuts ① on burner flange.
- ▶ Remove screws ③ between sound absorber and Venturi.
- ▶ Remove hoses on gas/air interconnection.



- ▶ Remove burner flange with gas/air interconnection ③.
- ▶ Remove gasket on burner flange ②.
- ▶ Remove burner tube ①.
- ▶ Remove deposits from combustion chamber.
- ▶ Check burner tube for visible damage, replace if necessary.



9 Servicing

Cleaning the burner tube

Clean burner tube if required:

- ▶ Clean the inside of the burner tube (if necessary use compressed air to blow through from outside to inside).
- ▶ If dust deposits are present, brush out burner fleece using a soft brush to prevent damaging the burner fleece.

Once finished cleaning, ensure that the fibres of the burner fleece do not stick out too far in the area near the ionisation electrode (danger of short circuit with ionisation electrode).

Refitting


- ▶ Refit burner tube in reverse order by:
 - fitting burner tube to locator pins in heat exchanger and ensuring correct alignment of groove pins,
 - replacing burner flange gasket and gas gasket,
 - and observing correct fitting of hoses (see Ch. 12.3).

9 Servicing

9.6 Cleaning the heat exchanger

Observe notes on servicing (see Ch. 9).

- ▶ Remove left panel.
- ▶ Remove service covers from heat exchanger ① and the condensate collector ④.
- ▶ Clean heat exchanger using the cleaning kit (accessory).
- ▶ Remove deposits from heat exchanger and condensate collector ②.
- ▶ Remove closing cap ③ and clean siphon.
- ▶ Fill siphon with water.
- ▶ Replace seals of service covers.
- ▶ Close all covers.




9 Servicing

9.7 Check flue gas pressure switch

Observe notes on servicing (see Ch. 9).

- ▶ Switch on main switch.
- ▶ Set boiler to Standby (see Ch. 6.2.2). If a remote control station is fitted, see operating instructions WCM-FS.
- ▶ Remove pressure measuring hose from test point ① on the condensate collector.
- ▶ Check pressure measuring hose for damage.
- ▶ Connect test equipment ②.
- ▶ Generate test pressure of > 5.5 mbar.
- ✓ The flue gas pressure switch functions correctly if the display shows F38.



- ▶ Reconnect pressure measuring hose.
- ▶ Reset system using [reset] button.
- ▶ Exit Standby mode.

10 Troubleshooting

10 Troubleshooting

10.1 Procedures for fault conditions



Damage resulting from incorrect servicing


The combustion plant could be damaged.

- ▶ Do not carry out more than 2 lockout resets successively.
- ▶ Faults must be rectified by qualified personnel.

Irregularities of the boiler operation are detected and indicated by a flashing display. A distinction is made between warnings and faults.

Warnings


A warning is indicated with a **W** and a number in the display. The signal will extinguish automatically as soon as the cause of the warning has been eliminated. The boiler does not lock out during a warning.



- ▶ Read the warning code.
- ▶ Rectify the cause of the warning with the aid of the table in chapter 10.3.1.
- ▶ If a warning appears more than once, the system should be checked by qualified personnel.

Faults

A fault is indicated with an **F** and a number in the display. If a fault occurs, the systems goes to lockout.



- ▶ Read the fault code.
- ▶ Rectify the cause of the fault using the table in chapter 10.3.2.
- ▶ Reset the fault using the reset button and wait for a few seconds.
- ✓ The system is reset.



If the fault cannot be reset using the [reset] button, briefly switch off power supply using switch S1.


10 Troubleshooting

10.2 Fault history

The last 6 faults and the system status at the time of the faults are recorded in the fault history.

Display the fault


- ▶ Activate the fault level (see Ch. 6.3).
- ✓ The most recent fault will be displayed.
- ▶ Turn the dial knob.
- ✓ Fault 1 ... 6 can be selected.



- ① Fault 1 ... 6
- ② Error codes

Interrogate the system status

- ▶ Select fault with dial knob.
- ▶ Press Enter button.
- ✓ System status when fault occurred is displayed.
- ▶ Turn the dial knob to interrogate the system status.



	Process value	Unit
10	Operating phase 0 = Burner off 1 = Standby check fan 2 = Prepurge speed achieved 3 = Prepurge 4 = Ignition speed achieved 5 = Ignition 6 = Burner in operation 7 = Gas valve check 8 = Post purge speed achieved and post purge	–
11	Rating	%
22 ⁽¹⁾	Setpoint speed pump	%
30	eSTL	°C
31	Flue gas temperature	°C
32	Ionisation signal	µA
37	Return temperature	°C
ESC	Exit menu	–

⁽¹⁾ Display only if speed controlled pump is fitted.

10 Troubleshooting

10.3 Rectifying faults

10.3.1 Warning codes

Warning code	Cause	Rectification
W12	Temperature at eSTL > 95 °C Temperature at supply sensor > 95 °C Temperature at return sensor > 95 °C	<ul style="list-style-type: none"> ▶ Check the water flow. ▶ Check function of the pumps. ▶ Vent boiler on the water side.
W14	Temperature at eSTL increases too rapidly	<ul style="list-style-type: none"> ▶ Check the water flow. ▶ Check function of the pumps. ▶ Vent boiler on the water side.
W15	Temperature differential between flow and return to high (The system goes to lockout after 30 warnings with F15)	<ul style="list-style-type: none"> ▶ Check function of pump, if necessary increase pump rating. ▶ Safeguard system circulation.
W16	Flue gas temperature is too high (see parameter 33)	<ul style="list-style-type: none"> ▶ Check the heat exchanger (see Ch. 9.6).
W18	Difference eSTL and flow temperature too great (The system goes to lockout after 30 warnings with F18)	<ul style="list-style-type: none"> ▶ Check function of the pumps. ▶ Safeguard system circulation.
W21	No flame formation when the burner starts (The system goes to lockout after 5 failed start attempts with F21)	<ul style="list-style-type: none"> ▶ Check the ignition unit and replace if necessary. ▶ Check gas combi valve and cable and replace if necessary. ▶ Check setting of gas combi valve. ▶ Clean or replace burner tube (see Ch. 9.5). ▶ Check phase of voltage supply.
W22	Flame failure during operation (the system goes to lockout with F21 after one failed restart)	<ul style="list-style-type: none"> ▶ Check the ionisation electrode and replace, if necessary (see Ch. 9.4). ▶ Check O₂ settings. ▶ Clean or replace burner tube (see Ch. 9.5).
W24	Input H2 is closed, parameter 17 = 3 (lockout function)	<ul style="list-style-type: none"> ▶ Check components connected to input H2 (see Ch. 6.10).
W33	External sensor is defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
W34	DHW sensor defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
W39	De-couple sensor defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
W47	Gas pressure insufficient WTC 120 < 13 mbar WTC 120 ... 300 < 11 mbar	<ul style="list-style-type: none"> ▶ Check gas connection pressure (see Ch. 7.1.2).
W57	Communication WCM-CPU and WCM-CUI faulty.	<ul style="list-style-type: none"> ▶ Check the connection ▶ Rectify electromagnetic disturbance source.
W80	Communication to the cascade manager is faulty	<ul style="list-style-type: none"> ▶ Check the connection ▶ Check the cascade manager. ▶ Check the address setting parameter 12. ▶ Check the feed in from the eBus.
W81	Communication to WCM-FS is faulty	<ul style="list-style-type: none"> ▶ Check the connection ▶ Replace the remote control station.
W82	Communication to EM#2 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.

10 Troubleshooting

Warning code	Cause	Rectification
w83	Communication to EM#3 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w84	Communication to EM#4 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w85	Communication to EM#5 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w86	Communication to EM#6 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w87	Communication to EM#7 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w88	Communication to EM#8 is faulty	<ul style="list-style-type: none"> ▶ Check address. ▶ Check the connection ▶ Replace the extension module.
w89	Remote control signal (input N1) faulty	<ul style="list-style-type: none"> ▶ Test the setpoint signal (see Ch. 6.7). ▶ Check the connection

10 Troubleshooting

10.3.2 Error codes

Error code	Cause	Rectification
F11	Temperature at eSTL > 105 °C	<ul style="list-style-type: none"> ▶ Check the water flow. ▶ Check function of the pumps. ▶ Vent boiler on the water side.
F15	Temperature differential between flow and return too high (see also W15)	<ul style="list-style-type: none"> ▶ Check function of pump, if necessary increase pump rating. ▶ Safeguard system circulation.
F18	Difference eSTL and flow temperature too great (see also W18)	<ul style="list-style-type: none"> ▶ Check function of the pumps. ▶ Safeguard system circulation.
F21	No flame formation when the burner starts (see also W21)	<ul style="list-style-type: none"> ▶ Check the ignition unit and replace if necessary. ▶ Check gas combi valve and cable and replace if necessary. ▶ Check setting of gas combi valve. ▶ Clean or replace burner tube (see Ch. 9.5). ▶ Check phase of voltage supply.
F23	Flame simulation	<ul style="list-style-type: none"> ▶ Check earth connections. ▶ Install mains filter. ▶ Check burner tube and ionisation electrode (short circuit). ▶ Reset appliance, replace WCM-CPU on repeat occurrence.
F30	eSTL defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
F31	Flue gas sensor is defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
F32	Switch contact of air pressure switch not in Standby	<ul style="list-style-type: none"> ▶ Check air pressure switch and cable and replace if necessary. ▶ Chimney draught too great.
F35	The supply sensor is defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
F36	Water pressure insufficient	<ul style="list-style-type: none"> ▶ Check system pressure and top up.
F37	return sensor defective	<ul style="list-style-type: none"> ▶ Check the sensor and cable and replace if necessary.
F38	Flue gas pressure switch does not drop out during the fan standby check	<ul style="list-style-type: none"> ▶ Check flue gas pressure switch and cable, if necessary replace.
F41	Gas valve (internal) leaking	<ul style="list-style-type: none"> ▶ Replace gas combi valve.
F43	Specified fan speed is not achieved	<ul style="list-style-type: none"> ▶ Check the fan and cable and replace if necessary.
F44	Fan standby defective	<ul style="list-style-type: none"> ▶ Check fan and replace if necessary.
F45	Air pressure switch does not switch (on/off pressure 1.6/1.4 mbar)	<ul style="list-style-type: none"> ▶ Check flue gas ducting and air supply. ▶ Check air pressure switch and cable and replace if necessary. ▶ Clean burner tube (see Ch. 9.5).
F46	Flue gas side pressure too high (release pressure 5.5 mbar)	<ul style="list-style-type: none"> ▶ Check flue gas ducting. ▶ Check flue gas pressure switch and cable, if necessary replace.
F48	Maximum run time of flue gas damper exceeded (see installation instructions WAL-PP)	<ul style="list-style-type: none"> ▶ Check flue gas damper and cable, if necessary replace.
F51	Data record error boiler	<ul style="list-style-type: none"> ▶ Check the BCC connector and replace if necessary. ▶ Restart configuration (see Ch. 6.5). ▶ Reset appliance, replace WCM-CPU on repeat occurrence.

10 Troubleshooting

Error code	Cause	Rectification
F52	Data record error burner	<ul style="list-style-type: none"> ▶ Check the BCC connector and replace if necessary. ▶ Reset appliance, replace WCM-CPU on repeat occurrence.
F53	Supply voltage or power frequency outside the tolerance limits	<ul style="list-style-type: none"> ▶ Check mains supply. ▶ Reset appliance, replace WCM-CPU on repeat occurrence.
F54	Electronic fault	<ul style="list-style-type: none"> ▶ Rectify electromagnetic disturbance source. ▶ Reset appliance, replace WCM-CPU on repeat occurrence.
F55	System has been reset too often (max 5 times within 5 minutes)	<ul style="list-style-type: none"> ▶ Temporarily interrupt voltage supply.
F57	Communication WCM-CPU and WCM-CUI faulty.	<ul style="list-style-type: none"> ▶ Check the connection ▶ Rectify electromagnetic disturbance source.


10 Troubleshooting

10.3.3 Operating problems

Observation	Cause	Rectification
Burner does not operate in spite of heat demand	Burner rapid cycle interlock activated eSTL, supply sensor, return sensor must lie within a temperature range of 4 K.	<ul style="list-style-type: none"> ► Wait for the cooling down. ► Check sensor and replace if necessary.
Whistling noises / burner booming	Incorrect combustion values	► Check combustion values
	Burner tube is contaminated/damaged	► Check the burner tube and replace if necessary
Smell of flue gas	Siphon fill level insufficient	► Fill siphon
Poor start behaviour	Ignition electrode set incorrectly or damaged	► Set ignition electrode, or replace if necessary
	Incorrect combustion values	► Check combustion values

11 Spares


11 Spares



11 Spares

Pos.	Description	Order No.
1.01	Grommet	481 011 40 22 7
1.02	Top part	
	– WTC 120 / WTC 170	482 101 02 18 7
	– WTC 210 / WTC 250 / WTC 300	482 301 02 18 7
1.03	Side panel left/right	
	– WTC 120 / WTC 170	482 101 02 19 7
	– WTC 210 / WTC 250 / WTC 300	482 301 02 19 7
1.04	Rear panel	482 101 02 21 2
1.05	Bracket flue gas elbow	
	– WTC 120 / WTC 170	482 101 02 22 7
	– WTC 210 / WTC 250 / WTC 300	482 301 02 22 7
1.06	Front panel	482 101 02 20 2
1.07	Spacer	401 110 02 20 7
1.08	Magnetic fastener	499 223
1.09	Plug 6 mm white	446 034
1.10	Operating panel complete (without boiler control panel)	482 101 22 09 2
1.11	Name plate -weishaupt- 125 x 35	793 815
1.12	Flap operating panel	482 101 22 12 7
1.13	Attachment for soft closing hinge	482 101 22 11 7
1.14	Soft closing hinge	482 101 22 21 7
1.15	Serrated lock washer	431 002
1.16	Cable duct 45 x 30	
	– WTC 120 / WTC 170	482 101 22 20 7
	– WTC 210 / WTC 250 / WTC 300	482 301 22 20 7
1.17	Sticky tape 19 x 50 mm	343 146
1.18	Cable tie with rivet	481 011 22 11 7
1.19	Cable holder WPC20 with anchor bolt	482 101 30 74 7
1.20	Spacer sleeve 5 x 10 x 10	482 101 02 26 7
1.21	Bracket fan locator	482 101 30 62 7
1.22	Unit foot M10	482 101 02 17 7
1.23	Air inlet grill DN 110 complete	482 101 31 02 2
1.24	Pipe PP DN 110	
	– 0.60 m (WTC 120 / WTC 170)	480 000 10 84 7
	– 0.85 m (WTC 210 / WTC 250 / WTC 300)	480 000 10 96 7
1.25	Gasket DN 110	669 212
1.26	Elbow PP DN 110 / 87 degrees	480 000 05 14 7
1.27	Bracket intake pipe top	482 101 31 04 7
1.28	Pipe PP DN 110 / 0,180 m	480 000 10 83 7
1.29	Bracket intake pipe bottom	482 101 31 03 7
1.30	Pipe PP DN 110 / 0.18 m with test nipple	480 000 10 89 2


11 Spares



11 Spares

Pos.	Description	Order No.
2.01	Cable tie with rivet	481 011 22 11 7
2.02	Grommet	481 011 02 23 7
2.03	Fixing plate operating unit	482 101 22 19 7
2.04	LCD cover	482 101 22 14 7
2.05	Enter button	482 101 22 33 2
2.06	Reset button	481 011 22 19 2
2.07	Screw M5 x 30	403 268
2.08	Boiler control panel	482 101 22 13 7
2.09	Printed circuit board KSF-FS	482 101 22 07 2
2.10	Screw PT KA22 x 6 H	409 368
2.11	Button WCM-CUI	482 101 22 15 7
2.12	On/Off switch knob	482 101 22 32 2
2.13	Screw PT KA30 x 10 H	409 367
2.14	Hose clamp 7.5	790 218
2.15	Hose 3.5 x 2.0 transparent	750 418
2.16	T connection	453 009
2.17	Air pressure switch 20-220 Pa	691 390
2.18	Flue gas pressure switch 5.5 mbar	482 101 30 68 2
2.19	Hose 6 x 2.0 black	750 421
2.20	Hose clamp 9.2 x 10.5 x 5	790 220
2.21	Ring clamp for pressure switch	482 101 22 18 7
2.22	Edge trim	401 110 02 08 7
2.23	Traction relief clamp	790 528
2.24	Screen connection terminal SK8	735 569
2.25	Connection box W-EAB with plug	482 001 22 02 2
2.26	Connection box housing top W-EAB	482 001 22 03 2
2.27	Boiler electronics set (WCM-CPU / WCM-CUI)	482 101 22 36 2
2.28	Coded plug BCC	
	– WTC 120	482 101 22 11 2
	– WTC 170	482 201 22 11 2
	– WTC 210	482 301 22 11 2
	– WTC 250	482 401 22 11 2
	– WTC 300	482 501 22 11 2
2.29	Micro fuse 6.3 AT	722 024
2.30	Grommet safety switch	482 101 22 34 7
2.31	Plug 230V 3pole black	716 275
2.32	Plug H1 2 pole turquoise	716 276
2.33	Plug H2 2 pole red	716 286
2.34	Plug MFA1 3 pole lilac	716 277
2.35	Plug MFA2 3 pole lilac	716 287
2.36	Plug VA1 2 pole brown	716 288
2.37	Plug eBUS 2 pole light blue	716 279
2.38	Plug B11 2 pole white	716 290
2.39	Plug B1 2 pole green	716 280
2.40	Plug B3 2 pole yellow	716 281
2.41	Plug 2 pole dark blue	716 283
2.42	Plug N1 2 pole orange	716 274
2.43	Jumper 2 pole	716 232


11 Spares



11 Spares

Pos.	Description	Order No.
3.01	Insulation	
	– WTC 120	482 101 30 42 7
	– WTC 170	482 201 30 42 7
	– WTC 210	482 301 30 42 7
	– WTC 250	482 401 30 42 7
	– WTC 300	482 501 30 42 7
3.02	Closing cap	
	– 1 1/4" (WTC 120 / WTC 170)	482 101 30 20 7
	– 1 1/2" (WTC 210 / WTC 210 / WTC 300)	482 301 30 20 7
3.03	Gasket	
	– 1 1/4" (WTC 120 / WTC 170)	482 101 30 43 7
	– 1 1/2" (WTC 210 / WTC 210 / WTC 300)	482 301 30 43 7
3.04	Double nipple	
	– 1 1/4" (WTC 120 / WTC 170)	482 101 30 17 7
	– 1 1/2" (WTC 210 / WTC 210 / WTC 300)	482 301 30 17 7
3.05	NTC flow/return sensor 5 kOhm G 1/4	482 101 40 01 7
3.06	Flow manifold	
	– WTC 120	482 101 30 71 2
	– WTC 170	482 201 30 71 2
	– WTC 210	482 301 30 71 2
	– WTC 250	482 401 30 71 2
	– WTC 300	482 501 30 71 2
3.07	Water level interlock G1/4 with plug cable	482 101 40 02 2
3.08	Seal water level interlock 20 x 13 x 2	482 101 40 03 7
3.09	Return manifold	
	– WTC 120	482 101 30 72 2
	– WTC 170	482 201 30 72 2
	– WTC 210	482 301 30 72 2
	– WTC 250	482 401 30 72 2
	– WTC 300	482 501 30 72 2
3.10	Nipple N4/1 - 3/4 x 1/2	453 084
3.11	Drain cock G 1/2 PN 10	454 090
3.12	Seal collector 42 x 32 x 3	482 101 30 21 7
3.13	Screw M8 x 30	401 510
3.14	Spring washer B 8 DIN 137	431 622
3.15	Reducing nipple R 3/4A x G 3/8I x 26	482 101 30 12 7
3.16	NTC-STL sensor 5 kOhm G 3/8	482 101 30 06 7
3.17	Gasket DN 160	669 296
3.18	Flue gas sensor NTC G 1/4	482 101 30 07 7
3.19	Pressure test nipple G1/4 x Dm6	482 101 30 16 7
3.20	Seal service cover heat exchanger	482 101 30 15 7
3.21	Service cover heat exchanger	482 101 30 14 7
3.22	Washer nut M6 A2G ISO 4042	412 508
3.23	Seal service cover condensate collector	
	– WTC 120 / WTC 170	482 101 30 13 7
	– WTC 210 / WTC 250 / WTC 300	482 301 30 13 7

11 Spares




11 Spares

Pos.	Description	Order No.
3.24	Service cover condensate collector	
	– WTC 120 / WTC 170	482 101 30 02 7
	– WTC 210 / WTC 250 / WTC 300	482 301 30 02 7
3.25	Union nut G 1 1/4 siphon	481 011 40 19 7
3.26	Seal siphon union nut G 1 1/4	481 011 40 21 7
3.27	O ring for cap	482 101 30 59 7
3.28	Cap siphon	482 101 30 58 7
3.29	Closing cap	482 101 30 57 7
3.30	Condensate hose 25 x 215 long	482 101 30 64 7
3.31	Hose clamp	499 151
3.32	Condensate hose 25 x 1000 long	400 110 50 21 7
3.33	Bracket siphon complete	482 101 30 60 2
3.34	Fillister head screw M5 x 65	482 101 30 61 7
3.35	Siphon complete	482 101 30 56 2
3.36	Screw M8 x 70	401 506
3.37	Spring washer B 8 DIN 127	435 250
3.38	Heat cell pre-mounted with gasket set and installation aid	
	– WTC 120	482 101 30 07 2
	– WTC 170	482 201 30 07 2
	– WTC 210	482 301 30 07 2
	– WTC 250	482 401 30 07 2
	– WTC 300	482 501 30 07 2

11 Spares

WTC 120




11 Spares

Pos.	Description	Order No.
4.01	Burner tube WTC 120	482 101 30 23 7
4.02	Gasket burner flange	482 101 30 24 7
4.03	Burner flange complete	482 101 30 64 2
4.04	Stud M4 x 20	420 451
4.05	Spring washer B8 DIN 137	431 622
4.06	Hexagonal nut M8 DIN 985 -5	411 408
4.07	Seal view port internal 26 x 35 x 2	481 401 30 11 7
4.08	View port glass	481 401 30 06 7
4.09	Seal view port external	482 101 30 50 7
4.10	View port cover	482 101 30 49 7
4.11	Nut M4 x 10 long SW 7	482 101 30 28 7
4.12	O ring 88.58 x 2.62 NBR 70	482 101 30 75 2
4.13	Fan RG175 with O rings	482 101 30 66 2
4.14	Screw M8 x 25	401 542
4.15	Ignition unit ZAG 1 220-240V 50-60Hz 10VA	603 189
4.16	Screw M4 x 10	402 150
4.17	Bracket ignition unit	482 101 30 77 7
4.18	Screw M6 x 10	402 366
4.19	Spacer M6 x 100	482 101 30 48 7
4.20	Screw M6 x 20	409 275
4.21	Cable tie with rivet	481 011 22 11 7
4.22	Ignition electrode with earth wire and gasket	482 001 30 26 2
4.23	Gasket ignition electrode	482 101 30 27 7
4.24	Ionisation electrode with gasket	482 101 30 08 2
4.25	Gasket ionisation electrode	482 101 30 44 7
4.26	Mixer Venturi complete WTC 120	482 101 30 70 2
4.27	O ring 110 x 3.5 NBR 70 DIN 3771	482 101 30 37 2
4.28	Screw M8 x 16 Torx	482 101 30 33 7
4.29	Sound absorber WTC 120	482 101 31 07 7
4.30	O ring 33 x 2 NBR 70 DIN 3771	482 101 30 32 2
4.31	Intermediate piece with threaded socket and O rings	482 101 30 74 2
4.32	Threaded socket R1/8	482 101 30 65 7
4.33	Hexagonal nut M5 DIN 985 -5	411 203
4.34	Flat head screw M5 x 18 ISO 7380	482 101 30 34 7
4.35	Screw M5 x 12	402 207
4.36	Compact gas combi valve with O rings WTC 120	482 101 30 69 2
4.37	O ring 26.57 x 3.53 NBR 70 DIN 3771	482 101 30 38 2
4.38	Pressure switch 13 mbar 240VAC with adapter	605 566
4.39	Gas connection piece complete WTC 120	482 101 30 51 2
4.40	Sealing ring 32 x 44 x 2 rubber cork R1'	441 011
4.41	Gas pipe with screw insert and gasket WTC 120	482 101 30 41 2
4.42	Pipe clamp for gas pipe 1"	482 101 30 46 7
4.43	Threaded rod M8 x 75	482 101 02 25 7
4.44	Washer A8.4	430 501
4.45	Hexagonal nut M 8	411 401

11 Spares

WTC 170 / WTC 210 / WTC 250 / WTC 300




11 Spares

Pos.	Description	Order No.
5.01	Burner tube	
	– WTC 170	482 201 30 23 7
	– WTC 210	482 301 30 23 7
	– WTC 250	482 401 30 23 7
	– WTC 300	482 501 30 23 7
5.02	Gasket burner flange	482 101 30 24 7
5.03	Burner flange complete	482 201 30 64 2
5.04	Stud M4 x 20	420 451
5.05	Spring washer B8 DIN 137	431 622
5.06	Hexagonal nut M8 DIN 985 -5	411 408
5.07	Seal view port internal 26 x 35 x 2	481 401 30 11 7
5.08	View port glass	481 401 30 06 7
5.09	Seal view port external	482 101 30 50 7
5.10	View port cover	482 101 30 49 7
5.11	Nut M4 x 10 long SW 7	482 101 30 28 7
5.12	O ring 123.4 x 3.53 NBR 70	482 201 30 67 2
5.13	Fan G1G170 with O rings	
	– AB53-41 (WTC 170 / WTC 210 / WTC 250)	482 201 30 66 2
	– AB31-44 (WTC 300)	482 501 30 66 2
5.14	Bolt M8 x 35 DIN 933 8.8	401 520
5.15	Ignition unit ZAG 1 220-240V 50-60Hz 10VA	603 189
5.16	Screw M4 x 10	402 150
5.17	Bracket ignition unit	482 101 30 77 7
5.18	Screw M6 x 10	402 366
5.19	Spacer M6 x 100	482 101 30 48 7
5.20	Screw M6 x 20	409 275
5.21	Cable tie with rivet	481 011 22 11 7
5.22	Ignition electrode with earth wire and gasket	482 001 30 26 2
5.23	Gasket ignition electrode	482 101 30 27 7
5.24	Ionisation electrode with gasket	482 101 30 08 2
5.25	Gasket ionisation electrode	482 101 30 44 7
5.26	O ring 110 x 3.5 NBR 70 DIN 3771	482 101 30 37 2
5.27	Round head screw M8 x 12 ISO 7380	482 201 30 34 7
5.28	Mixer Venturi complete	
	– WTC 170	482 201 30 70 2
	– WTC 210 / WTC 250 / WTC 300	482 301 30 70 2
5.29	Closing plug 1/8	482 201 30 43 7
5.30	Sound absorber	
	– WTC 170	482 101 31 01 7
	– WTC 210	482 301 31 01 7
5.31	Connection flange air intake Venturi	482 401 31 05 7
5.32	Screw M6 x 20	402 350
5.33	Washer A6.4	430 400
5.34	Compact gas combi valve with O rings	
	– VR420 (WTC 170)	482 201 30 69 2
	– VR425 (WTC 210 / WTC 250 / WTC 300)	482 301 30 69 2
5.35	O ring 52.39 x 3.53 NBR 70 DIN 3771	482 201 30 05 2
5.36	Screw M5 x 12	402 207

11 Spares

WTC 170 / WTC 210 / WTC 250 / WTC 300




11 Spares

Pos.	Description	Order No.
5.37	Pressure switch 5-40 mbar 250VAC	605 575
5.38	Gas connection piece complete WTC 170	482 201 30 51 2
5.39	Screw M5 x 16	402 208
5.40	Sealing ring 32 x 44 x 2 rubber cork R1'	441 011
5.41	Gas pipe with screw insert and gasket	
	– WTC 170	482 201 30 41 2
	– WTC 210 / WTC 250 / WTC 300	482 301 30 41 2
5.42	Pipe clamp for gas pipe 1"	482 101 30 46 7
5.43	Threaded rod M8 x 75	482 101 02 25 7
5.44	Washer A8.4	430 501
5.45	Hexagonal nut M 8	411 401

11 Spares

WTC 120




11 Spares

Pos.	Description	Order No.
6.01	Plug cable fan control	482 101 22 26 2
6.02	Plug cable fan 230V	482 101 22 27 2
6.03	Ionisation electrode with gasket	482 101 30 08 2
6.04	Plug cable ignition transformer	482 101 22 28 2
6.05	Ignition cable	482 001 30 28 2
6.06	Plug cable gas valve	482 101 22 29 2
6.07	Plug cable low gas pressure switch	482 101 22 23 2
6.08	Plug cable flue gas sensor	482 101 22 25 2
6.09	Water level interlock with plug cable	482 101 40 02 2
6.10	Plug cable SELV signals	482 101 22 21 2
6.11	Plug cable eSTL, B12, B13	482 101 22 22 2
6.12	Plug cable air pressure switch	482 101 22 24 2
6.13	Plug cable H1 H2	482 101 22 18 2
6.14	Plug cable pressure switch flue gas	482 101 22 31 2
6.15	Plug cable mains 230V	482 101 22 19 2
6.16	Chassis earth GNGE 1.0 x 240 Chassis-PE	482 101 22 30 2

11 Spares

WTC 170 / WTC 210 / WTC 250 / WTC 300




11 Spares

Pos.	Description	Order No.
7.01	Plug cable fan control	482 101 22 26 2
7.02	Plug cable fan 230V	482 101 22 27 2
7.03	Ionisation electrode with gasket	482 101 30 08 2
7.04	Plug cable ignition transformer	482 101 22 28 2
7.05	Ignition cable	482 001 30 28 2
7.06	Plug cable gas valve	482 201 22 29 2
7.07	Plug cable low gas pressure switch	482 201 22 23 2
7.08	Plug cable flue gas sensor	482 101 22 25 2
7.09	Water level interlock with plug cable	482 101 40 02 2
7.10	Plug cable SELV signals	482 101 22 21 2
7.11	Plug cable eSTL, B12, B13	482 101 22 22 2
7.12	Plug cable air pressure switch	482 101 22 24 2
7.13	Plug cable H1 H2	482 101 22 18 2
7.14	Plug cable pressure switch flue gas	482 101 22 31 2
7.15	Plug cable mains 230V	482 101 22 19 2
7.16	Chassis earth GNGE 1.0 x 240 Chassis-PE	482 101 22 30 2

11 Spares

8.01




11 Spares

Pos.	Description	Order No.
8.01	Service set	
	Consisting of:	
	▪ Gasket burner flange	
	▪ Ignition electrode with earth cable	
	▪ Gasket ignition electrode	
	▪ Ionisation electrode	
	▪ Gasket ionisation electrode	
	▪ Sealing ring 32 x 44 x 2 rubber cork R1'	
	▪ Seals service cover heat exchanger	
	▪ Seal service cover condensate collector	
	– WTC 120	482 101 00 16 2
	– WTC 170	482 201 00 16 2
	– WTC 210	482 301 00 16 2
	– WTC 250	482 401 00 16 2
	– WTC 300	482 501 00 16 2

12 Technical documentation

12 Technical documentation

12.1 Internal boiler wiring



- ① eSTL
- ② Flow sensor
- ③ Return sensor
- ④ Flue gas sensor
- ⑤ Fan control
- ⑥ Gas pressure switch
- ⑦ Air pressure switch
- ⑧ Flue gas pressure switch
- ⑨ Water level interlock
- ⑩ Ionisation
- ⑪ Ignition unit
- ⑫ Fuel valves (gas combi valve)
- ⑬ Fan motor

12 Technical documentation


12.2 Sensor variables

eSTL Return sensor Flow sensor De-couple sensor Flue gas sensor		External sensor(QAC 31)		DHW sensor (B3)	
NTC 5 kΩ		NTC 600Ω		NTC 12 kΩ	
°C	Ω	°C	Ω	°C	Ω
-20	48180	-35	672	-15	71800
-15	36250	-30	668	-10	55900
-10	27523	-25	663	-5	44000
-5	21078	-20	657	0	35500
0	16277	-15	650	5	27700
5	12669	-10	642	10	22800
10	9936	-8	638	15	17800
15	7849	-6	635	20	14800
20	6244	-4	631	25	12000
25	5000	-2	627	30	9800
30	4029	0	623	35	8300
35	3267	2	618	40	6600
40	2665	4	614	45	5400
45	2185	6	609	50	4500
50	1802	8	605	55	3800
55	1494	10	600	60	3200
60	1245	12	595	65	2700
65	1042	14	590	70	2300
70	876	16	585	75	2000
75	740	18	580	80	1700
80	628	20	575	85	1500
85	535	22	570	90	1300
90	457	24	565		
95	393	26	561		
100	338	28	556		
105	292	30	551		
110	254	35	539		

12 Technical documentation


12.3 Pneumatic control lines

12.3.1 Air pressure switch connection diagram



- ① Air pressure switch (on/off pressure 1.6/1.4 mbar)
- ② Gas combi valve
- ③ Venturi
- ④ Air inlet

12.3.2 Flue gas pressure switch connection diagram



- ① Flue gas pressure switch (release pressure 5.5 mbar)
- ② Condensate collector

12 Technical documentation

12.4 Conversion table O₂/CO₂

O ₂ content dry in %v	CO ₂ content in %		
	Natural Gas E (max 11.7 % CO ₂)	Natural Gas LL (max 11.5 % CO ₂)	Propane (max 13.7 % CO ₂)
2.2	10.5	10.3	12.3
2.6	10.3	10.1	12.0
3.0	10.0	9.9	11.7
3.4	9.8	9.6	11.5
3.8	9.6	9.4	11.2
4.2	9.4	9.2	11.0
4.6	9.1	9.0	10.7
5.0	8.9	8.8	10.4
5.4	8.7	8.5	10.2
5.8	8.5	8.3	9.9
6.2	8.2	8.1	9.7
6.6	8.0	7.9	9.4
7.0	7.8	7.7	9.1
7.4	7.6	7.4	8.9
7.8	7.4	7.2	8.6
8.2	7.1	7.0	8.4

13 Notes

13 Notes

14 Key word index

A		Fan speed	15, 19
Adjusting	58	Fault conditions	73
Adjustment	23	Fault history	74
Air inlet pipe	10	Faults	73
Air pressure	61	Filling the water	27
Air pressure switch	11, 12	Flow limit	8
Air supply ducting	30	Flow manifold	10
Ambient conditions	14, 18	Flow rate	8
Approval data	14, 18	Flue gas mass flow rate	16, 20
		Flue gas pressure switch	11, 12
B		Flue gas sensor	11, 12
Boiler circuit pump	48	Flue gas system	16, 20, 30
Boiler control panel	11	Flue gas temperature	16, 20
Boiler efficiency factor	16, 20	Flue gas testing	59, 60
Boiler electronics	11	Frost protection	49
Boiler frost protection	49	Fuel	14, 18
Boiler temperature	15, 19	Function	13
Breaks in operation	62	Fusing	14, 18
Burner rapid cycle interlock	46		
Burner rating	61	G	
Burner tube	70	Gas characteristics	29
		Gas combi valve	11
C		Gas connection pressure	29, 57
Chimney sweep	54	Gas isolating valve	29
Clearances	23	Gas pipe	10
Combustion air	8	Gas pressure switch	12
Combustion test	59, 60	Gas supply	29
Commissioning	55, 58	Gradient	12
Condensate	9, 28	Guarantee	7
Condensate collector	10		
Condensate connection	28	H	
Condensate lift pump	28	Heat exchanger	10, 71
Condensate quantity	15, 19	Heating engineer level	38
Configuration	45, 58	Heating water	24
Connection box	11		
Connection diagram	32	I	
Connection pressure	29, 57	Ignition electrode	11, 67
		Ignition electrode distance	67
D		Ignition unit	11
De-couple control	48	Info level	39
DHW frost protection	49	Inlet and outlet tap	10
DHW operation	46	Input	50
Dimension	17, 21	Installation	23
Display	35	Installation location	23
Disposal	9	Installation room	8
		Ionisation current	39
E		Ionisation electrode	11, 67
Electrical data	14, 18		
Electrical installation	31	L	
Emission	14, 18	Liability	7
Emission class	14, 18		
Emissions	14, 18	M	
End user level	36	Monitoring current	39
Error code	77		
External sensor	46	N	
		Neutralisation system	28
F		Normal volume	61
Fan	11		

14 Key word index

O

O ₂ content	14, 18, 59, 60, 103
Operating panel	11, 34
Operating phase	39, 74
Operating pressure	15, 19
Operating problems	79
Operating volume	61
Output	50

P

Parameter Level	41
Power consumption	14, 18
Pre-fuse	14, 18
Pressure loss	15, 19
Pressure switch	12
Program sequence	13
Pump control logic	48

R

Rating	15, 19, 44
Residual supply pressure	16, 20
Return manifold	10
Return sensor	11
Room air independent	8

S

Safety measures	8
Safety temperature limiter	12
Safety temperature sensor	11
Sensor variables	101
Sequence diagram	13
Service	63
Service display	65
Service interval	63, 65
Service life	8
Service notification	65
Service set	99
Shutdown	62
Shutdown time	62
Siphon	10, 28
Smell of flue gas	8, 79
Smell of gas	8
Sound absorber	10
Soundness test	56
Spanner	65
Spare part	81
Special level	46
Standard efficiency	15, 19
Standards	14, 18
Standby loss	16, 20
Storage	14, 18
Supply sensor	11
Supply voltage	14, 18
System frost protection	49

T

Tap	49
Temperature	14, 18

Temperature differential	12
Temperature remote control	47
Throughput limit	15, 19
Transport	14, 18, 22
Type key	10
Type of gas	14, 18











V

Venting	29
Venturi	10
Voltage supply	14, 18

W

Warning code	75
Warnings	73
Water connection	27
Water content	15, 19
Water hardness	24
Water level interlock	11, 12
Water treatment	26
Weight	17, 21
Whistling noise	79
Wiring diagram	32, 100

– weishaupt –

Product		Description	Performance
	W-Burners	The compact series, proven millions of times over: Economical, reliable, fully automatic. Gas, oil and dual fuel burners for domestic and commercial applications. The purflam burner gives almost soot-free combustion of oil with greatly reduced NO _x emissions.	Up to 570 kW
	Monarch and industrial burners	The legendary industrial burner: Tried and tested, long lived, clear construction. Gas, oil and dual fuel burners for district heat provision.	Up to 11,700 kW
	multiflam® burners	Innovative Weishaupt technology for large burners: Minimal emission values particularly at ratings over one megawatt. Oil, gas and dual fuel burners with patented fuel distribution system.	Up to 17,000 kW
	WK industrial burners	Modular powerhouses: Adaptable, robust, powerful. Oil, gas and dual fuel burners for industrial plant.	Up to 22,000 kW
	Thermo Unit	The Thermo Unit heating systems from cast iron or steel: Modern, economic, reliable. For environmentally friendly heating. Fuel: Gas or oil as desired.	Up to 55 kW
	Thermo Condens	The innovative condensing boilers with the SCOT system: Efficient, low in emissions, versatile. Ideal for domestic heating. Floor standing gas condensing boiler with ratings of up to 1200 kW (cascade), for higher heat demands.	Up to 1,200 kW
	Heat pumps	The heat pump programme offers solutions for utilisation of heat from air, soil and ground water. The systems are suitable for refurbishment or new builds. It is possible to use several heat pumps in cascade operation.	Up to 130 kW
	Solar systems	Free energy from the sun: Perfectly coordinated components, innovative, proven. Pleasantly shaped flat roof collectors to support heating and of domestic water	
	Water heater / energy reservoir	The attractive domestic water heating range includes classic water heaters which are supplied through a heating system and energy reservoirs which can be fed through solar systems.	
	Control technology / building management	From control panels to complete building management systems – at Weishaupt you can find the entire spectrum of modern control technology. Future oriented, economical and flexible.	